

USER GUIDE

**SONIM
XP3.20 QUEST
PRO**

English


sonim®
BUILT FOR LIFE™

Copyright © 2009 Sonim Technologies, Inc.

SONIM, Sonim Xperience, Sonim Xtend and the Sonim logo are trademarks of Sonim Technologies, Inc. Other company and product names may be trademarks or registered trade- marks of the respective owners with whom they are associated.

Disposal of Old Electrical and Electronic Equipment



The symbol of the crossed-out wheeled bin indicates that within the countries in the European Union, this product, and any enhancements marked with this symbol, can not be disposed as unsorted waste but must be taken to separate collection at their end- of-life.

Disposal of Battery



Please check local regulations for disposal of batteries. The battery should never be placed in municipal waste. Use a battery disposal facility if available.

General Information-----7

Phone Models Covered
 Network Services
 Sonim Support Information
 Use the Guide Effectively
 Options Commonly Used across Menu Items

Your Safety Guidelines-----9

Battery Performance
 Battery Replacement
 Avoid Short Circuit
 Avoid High Temperatures
 Battery Disposal
 Personal Medical Devices
 Child Safety
 Emergency Calls
 SAR Information

Getting Started-----14

Getting Started
 Battery Usage
 Inserting the Battery
 Removing the Battery
 Charging the Battery
 Set Battery Alert
 Your SIM Card
 Inserting the SIM Card
 Removing the SIM Card
 Switching On
 Home Screen
 Key Shortcuts in Home Screen
 Basic Settings
 Keypad Functions

Your Sonim XP3.20 Phone-----25

Your Sonim XP3.20 Phone
 Main Menu
 Main Menu Icons
 Home Screen Indicators
 Key Operations without Your SIM Card

Phone Settings-----29

Phone Settings
 General Settings
 Display Settings
 Sound Settings
 Connectivity Settings

Calls-----34

Calls
 Dial a Number
 Dial an International Number
 Dial a Number via Contacts
 Dial a Number via the Calls List
 Managing Call List
 Speed Dial
 Receive a Call
 Auto Answer
 Anykey Answer
 Minute Reminder
 Call Services
 Call Forwarding
 Call Barring
 Fixed Number Dialing
 Auto Redial
 Filter Calls
 Add to Black list
 Recording a Call

Managing Contacts-----40

Managing Contacts
 Add a New Contact
 Dialing a Number from Contacts
 Sending a Message from Contacts
 Add a New Contact in Group
 Group Settings
 Special Numbers
 Default Contact List
 Default Contact Location
 Sending Contact
 Delete Contacts
 Copy or Move Numbers between Phone and SIM

Adding a Contact to Blacklist
 Adding a Contact to Whitelist
 Searching Contacts

Messages ————— 43

Messages
 Advanced Settings
 Text Input Mode
 Write Messages
 Send a Message via Contacts
 Call or Save a Number Embedded in a Received
 Message
 Manage Your Messages
 Inbox
 Outbox
 Draft Messages
 Sent Messages
 Predefined Messages
 View SMS Memory
 Voice Mail
 SIM Card Menu

Hardcoded Shortcuts ————— 48

Hardcoded Shortcuts

WAP Browser ————— 49

WAP Browser

Opera Mini ————— 50

Opera Mini
 Configuration of APN (Access Point Name) for Opera
 Mini
 Installation of Opera Mini
 Launching Opera Mini

Java ————— 51

Java
 Installing Pre-bundled Java Applications
 Java Help
 Installing Java Application from SD Card
 Installing Java Application from WAP

Tools ————— 52

Tools
 Alarm
 Bluetooth
 USB Function
 Calendar
 Calculator
 Voice Recorder
 Audio Playback
 AGPS
 Stopwatch
 Unit Converter
 Countdown Timer

FM Radio ————— 58

FM Radio

Camera ————— 59

Camera
 Camera Options

Flashlight ————— 60

Flashlight

Micro SD Card ————— 61

Micro SD (Secure Digital) Card
 Inserting Micro SD Card into the Phone

Managing Your Files ————— 62

Managing Your Files

Wired Headset ————— 63

Wired Headset
 During Calls

End User License Agreement ————— 64

Unconditional 3 Year Guarantee
 Our Guarantee
 What We Will Do
 Phone Care
 Conditions

FCC-----**67**

FCC Statement

Declaration of Conformity-----**68**

Declaration of Conformity

Index-----**69**

3 **UNCONDITIONAL**
3 YEAR GUARANTEE

Congratulations on the purchase of a Sonim XP3.20™ mobile phone. This phone is a GSM/GPRS/EDGE enabled handset with tri-band capabilities and has an intuitive, feature-rich user interface, which allows you to make the best use of the offered functions.

Phone Models Covered

This user guide covers two Sonim XP3.20™ phone models: XP3.20-E and XP3.20-A. These two models contain an identical scope of features and differ only in the supported set of radio frequencies:

- Sonim XP3.20-E Quest Pro (GSM 900/1800/1900 MHz)
- Sonim XP3.20-A Quest Pro (GSM 850/1800/1900 MHz)

The model name can be read on the phone label under the battery. In this User Guide, both models are referred to as Sonim XP3.20, except for the few places where information corresponding to a specific model (that is, XP3.20-A or XP3.20-E) can be found.

Network Services

These are additional services that you can avail through your network service provider. To make the best of these services, you must subscribe to them through your service provider and obtain instructions for their use from your service provider.

Sonim Support Information

For additional product and support information, visit www.sonimtech.com.

Use the Guide Effectively

Familiarize yourself with the terminology and symbols used in the guide to help you use your phone effectively.

HOME SCREEN

This is the screen displayed when the phone is in idle condition.

PRESS

Means to press and release a key immediately. For example, Press 2 means that you press the key on the keypad that is labelled with the numeral 2 and the alphabets “ABC”.

SELECT

Means to either press the Left or Right Selection Key to apply the command indicated at the bottom of the screen. The Center navigation key can also be used to select options. For example, if this guide says **Select Menu > Messages > Create message**, you must press the Left Selection Key to select Menu, scroll to Messages and press the Left Selection Key, scroll to Create message and press the Left Selection Key. To return to the previous screen, press the Right Selection Key.

PRESS & HOLD

Means to press and hold a key for 2 seconds before releasing the key. This action is typically used when trying to switch on/off the phone or when using shortcuts to access specific functions. For example: press and hold 1 to access voicemail.

MENU OPTIONS

These options are displayed at the bottom of the screen. The selection keys are used to accomplish the indicated option.

SELECT MENU

Means to press the **Left Selection Key** to select the **Menu** option or press the Menu key (centre) for the same result.

A MENU ITEM SUFFIXED WITH THREE DOTS (...)

Means more options are available but only one has been mentioned in the guide.



Signifies a Note.

Options Commonly Used across Menu Items

The following are common actions used across various menu items:

EXIT

Displays the previous screen. Use the Right Selection key to perform this function.

CLEAR

Deletes data character by character. Use the Right selection key to perform this function.

OK

Confirms an action. Use the Left Selection Key or the Menu key to perform this function.

Please read and understand the following safety guidelines before you use the phone. These guidelines provide details to enable you to operate your phone safely and conform to any legal requirements regarding the use of cellular phones.



Do not use the phone at a refuelling point. Observe restrictions when using radio equipment at fuel depots, chemical plants or where blasting operations are in progress.



Electrical interference may obstruct the use of your phone. Observe restrictions in hospitals and near medical equipment.



Switch off your cellular phone when in an aircraft. Wireless phones can cause interference or danger to an aircraft. In an aircraft, the phone can be used in flight mode.



Do not expose the battery to high temperatures (in excess of 60°C).



Adhere to road safety laws. Do not hold/use a phone while you are driving; find a safe place to stop first. Do not speak into a hands-free microphone while you are driving.



Avoid using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids.



Use only Sonim XP3.20 approved charging equipment to charge your phone and avoid damage to your phone.



The symbol of the crossed-out wheeled bin indicates that within the countries in the European Union, this product, and any enhancements marked with this symbol, can not be disposed as unsorted waste but must be taken to separate collection at their end-of-life.





Ensure that only qualified personnel install or repair your phone.



The Sonim XP3.20 is water-proof and can be submerged to 1 metre for 30 minutes. It can work for 30 minutes if immersed. However, it is not waterproof in deeper water, during charging or when the system connector cover on bottom of the phone is open or compromised.

- To keep your phone waterproof, make sure that the connector cover located at the bottom is firmly plugged in every time it is open for charging or use of a wired headset
- Water droplets may form on the connector cover when it is opened soon after immersion. This does not indicate water leakage. The connector cover is sealed and waterproof.
- Water droplets may condense under the display cover if the phone is immersed in water with significant drop in temperature. This does not indicate water leakage. The droplets will disappear at room temperature.

The Sonim XP3.20 is dust-resistant, rugged and shock-resistant. However, it is not dust-proof or un-breakable if subjected to overwhelming impact. For best results and long product life, one should protect the Sonim XP3.20 from salt water, dust and strong impacts.



Make back-up copies of important information stored in your phone or maintain a written record.

Battery Performance

A rechargeable battery powers your device. Use the battery only for its intended purpose. Never use any charger or battery that is damaged. If the battery is completely discharged, it may take a few minutes before the charging indicator appears on the display or before any calls can be made. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times but it will eventually wear out. Unplug the charger from the electrical plug and the device when not in use. Ensure that you do not leave the fully charged battery connected to a charger. If left unused, a fully charged battery will lose its charge over time.

Battery Replacement

When the talk and standby times are noticeably shorter than normal, replace the battery with an original Sonim battery. If a replacement battery is being used for the first time or if the battery has not been used for a prolonged period, it may be necessary to connect the charger and then disconnect and reconnect it to begin charging the battery.

Avoid Short Circuit

Do not short-circuit the battery. An accidental short-circuit can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) This might happen, for example, when you carry a spare battery in your pocket or purse. A short-circuit at the terminals may damage the battery or the connecting object.

Avoid High Temperatures

Leaving the battery in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. For the best results, try to keep the battery between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Battery Disposal

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations and recycle when possible. Do not dispose as household waste. Do not dismantle, open or shred cells or batteries. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. In the event of a leak or a hazard seek **11** medical help immediately.

Personal Medical Devices

Mobile phones may affect the operation of cardiac pacemakers and other implanted equipment. Please avoid placing the mobile phone over the pacemaker, for example, in your breast pocket. When using the mobile phone, place it at the ear opposite the pacemaker. If a minimum distance of 15 cm (6 inches) is kept between the mobile phone and the pacemaker, the risk of interference is limited. If you suspect that interference is taking place, immediately turn off your mobile phone. Contact your cardiologist for more information. For other medical devices, consult your physician and the manufacturer of the device. Comply with instructions to switch off the device or deactivate the RF transmitter function when required, especially when posted in hospitals and aeroplanes. Equipment used in these places may be

sensitive to radio waves emitted from the device and adversely affect their operation. Also, observe restrictions at gas stations or other areas with flammable atmosphere or when close to electro-explosive devices.

Child Safety

Do not allow children to play with your mobile phone or its accessories. Keep it out of their reach. They could hurt themselves or others, or could accidentally damage the mobile phone or accessories. Your mobile phone and its accessories may contain small parts, which could be detached and create a choking hazard.

Emergency Calls

Mobile phones operate using radio signals, which cannot guarantee connection under all conditions. Therefore you should never rely solely upon any mobile phone for essential communications (e.g. medical emergencies). Emergency calls may not be possible in all areas, on all cellular networks, or when certain network services and/or mobile phone features are in use. Check with your local service provider.

SAR Information

The Sonim XP3.20 has been certified in compliance with the Government's requirements for exposure to Radio Waves.

When communicating over the wireless network, the mobile phone emits low radio waves known as radio frequency energy or RF. The Specific Absorption Rate or SAR is the unit used to measure the amount of RF energy absorbed by the body while using the phone and is expressed in watts/kilogram (W/kg).

Governments around the world have adopted comprehensive international safety guidelines, developed by scientific organizations, for example, ICNIRP (International Commission on Non-Ionizing Radiation Protection) and IEEE (The Institute of Electrical and Electronics Engineers Inc.), through periodic and thorough evaluation of scientific studies. These guidelines establish permitted levels of radio wave exposure for the general population.

Tests for SAR are conducted using standardized methods with the phone transmitting at its highest certified power level in all used frequency bands.

SAR Data Information for residents in countries that have adopted the SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP). For example, European Union, Japan, Brazil and New Zealand.

The limit recommended by ICNIRP is 2 W/kg averaged over ten (10) gram of tissue.

The highest SAR value for the Sonim XP3.20-E phone when tested by Sonim for use at the ear is 0.582 W/kg (10g).

Note: For countries, which require SAR measurements for body-worn operation:

- The highest SAR value for the Sonim XP3.20-E phone tested by Sonim for use when worn on the body is 0.644 W/kg (10g), provided that the phone is used with a non-metallic accessory with the handset at least 1.5 cm from the body, or with the original Sonim accessory intended for this phone and worn on the body.

The highest SAR value for the Sonim XP3.20-A phone when tested by Sonim for use at the ear is 0.253 W/kg (10g).

SAR Data Information for residents in the United States and Canada.

In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kilogram averaged over one gram of tissue. The standard incorporates a margin of safety to give additional protection for the public and to account for any variations in measurements.

Before a phone model is available for sale to the public in the US, it must be tested and certified by the Federal Communications Commission (FCC) that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (that is, by the ear and worn on the body) as required by the FCC for each model. The FCC has granted an Equipment Authorization for Sonim XP3.20 with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. While there may be differences between the SAR levels of various phones, all mobile phones granted an FCC equipment authorization meet the government requirement for safe exposure.

The highest SAR value for the Sonim XP3.20-A phone when tested by Sonim for use:

- By the ear is 0.557 W/kg (10 g).
- Worn on the body is 0.532 W/kg (10 g) for speech and 0.519 W/kg (10 g) for data calls.

The highest SAR value for the Sonim XP3.20-E phone when tested by Sonim for use:

- By the ear is 0.204 W/kg (10 g).
- Worn on the body is 0.153 W/kg (10 g) for speech and

0.275 W/kg (10 g) for data calls.

For body-worn operation, this phone meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory with the handset at least 1.5 cm from the body, or with the original Sonim accessory intended for this phone and worn on the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

Getting Started

This section provides information on using your Sonim XP3.20 phone.

The list of items in the Sonim XP3.20 phone box are:

- User Guide CD
- Sonim 3 Year Warranty Flyer
- Quick Start Guide
- Screwdriver
- Wired Headset
- USB Cable
- Charger
- Belt Clip

Battery Usage

- Use only a Sonim XP3.20 certified battery that is designed for this phone model.
- The use of other batteries may void the warranty terms of your phone and cause damage.
 - It is recommended to protect the battery from extreme temperature environments and moisture.
- Please keep the battery out of the reach of children.

Inserting the Battery


1 Unscrew Cover

To open the battery cover, rotate both the battery cover screws in an anti-clockwise direction (as shown in the figure). Sometimes, the battery cover may be tight and some extra effort is required to open it. You can use the screwdriver provided to open the screws.



2 Lift Cover

Lift the back cover to reveal the battery slot.



3 Insert Battery

Insert the battery and flush into the battery slot such that the three metallic contacts at the top of the battery are aligned with the metallic contacts within the battery compartment.



4 Close Cover

Close the battery cover. Rotate the battery cover screws in clockwise direction. You can use the screwdriver provided to tighten the screws.

Removing the Battery

Follow steps 1 and 2 of “Inserting the Battery” on page 14.

To remove the battery, lift the cover behind the phone and raise the upper end of the battery from the slot.

The battery can now be removed.

Follow step 4 of “Inserting the Battery” on page 14 to close the cover.

Charging the Battery

The battery delivered with your mobile phone is not fully charged. We recommend that you charge your mobile for 5 hours before you use your mobile phone for the first time.




The phone with a fully charged battery can remain in the standby mode for a duration of up to 1500 hours. If the battery is completely out of charge, it can take several minutes for the charging icon to appear when the charger is connected.

1 Insert Charger

Insert the charger plug into a power outlet.

2 Connect to Phone

Insert the mini USB connector of the charger to the socket at the bottom of the phone.



3 Charging Animation

If the battery is being charged when the phone is switched off, only the battery icon is displayed (as shown in the adjacent figure).



4 Charging Icon

If the battery is being charged while the phone is switched on, you will notice that the bars in the battery charge icon (visible on the home screen) show movement indicating that the battery is being charged. After the phone is fully charged the battery bars on the display stop scrolling. You can disconnect the charger from the phone.



CAUTION: There is a risk of explosion while charging if the battery has been replaced by an incorrect type.

Set Battery Alert

When you set the battery alert, every time the battery charge is low you hear an alarm. To set the battery alert select **Menu > Settings > Sounds tab > Battery alert**. Select **On** to activate the alert.

Your SIM Card

Purchase a SIM card from your mobile operator. The SIM card associates your network services (for example, phone number, data services, and so on) with your phone.

Inserting the SIM Card

1 Switch Off Phone

Ensure that the phone is switched off.

2 Lift Cover

Lift the battery cover and remove the battery. For instructions refer **“Inserting the Battery” on page 14**.

3 Place SIM Card

Place the SIM card by pushing it upward in the designated slot located under the battery.



4 Lock Cover

Reinsert the battery and the cover. Turn the battery cover screws clockwise to lock the battery cover.

Removing the SIM Card

1 Switch Off Phone

Ensure the phone is switched off.

2 Lift Cover

Lift the battery cover and remove the battery. For instructions refer **“Inserting the Battery” on page 14**.

3 Remove SIM Card

Remove the SIM card by pushing it downward from the slot.

4 Lock Cover

Reinsert the battery and the cover.

Parts of the Sonim XP3.20 Phone

The Sonim XP3.20 keypad has 9 function keys and 12 alphanumeric keys. The left side of the phone has one key and the right side of the phone has three keys.



Parts of the Sonim XP3.20 Phone



* PTT will only work if it is enabled. Check with the service provider.

Sonim XP3.20 Keypad

The following figure identifies different keys in the phone keypad. Numeric keys and arrow keys can be configured as shortcut keys. The figure shows the permanent short cuts. For configuring other shortcut keys, please refer **“Shortcuts”** on page 31.




Some features are enabled only if the SIM card is present.

Switching On

When the phone is switched on, it tries to register with the network. After successful registration, the name of the service provider is displayed.

Home Screen

Certain information is displayed when the phone is in standby mode, for example, the name of the service provider, date and time, battery charge status, GPRS connectivity. Other indicators may be displayed (if the feature is activated), like the alarm, call forward and so on.



Key Shortcuts in Home Screen

The following can be accessed from the home screen.

Press	To Access
Menu Key	Main Menu
Left Selection Key	Main Menu
Right Selection Key	Contacts
Call/Accept/Send Key	All Calls List
Up Arrow	Java Applications List
Down Arrow	Contacts
Right Arrow	Create Message
Left Arrow	FM Radio



The four functions that are performed using the arrow keys are set as factory defaults, however they can be changed. Select **Menu > Settings > General tab > Shortcuts**. Go to the second tab. Select the arrow key and select **Option > Change**. You can also change many of the shortcuts. Select **Menu > Settings > General tab > Shortcuts**. Select the key and select **Option > Change**.

Basic Settings

Security Settings

To prevent unauthorised use of your phone, you can set a PIN code. The PIN is operator dependent.

1. Select **Menu > Settings > General tab > Security settings > PIN code > On**. Enter the PIN. Select **OK**. After this is set, every time you power on the phone, you will be requested to enter the PIN. If the PIN code is wrong you cannot access the phone.
2. To change the PIN code select **Menu > Settings > General tab > Security settings > Change password**. You can change codes for PIN, PIN2, Call barring, Safeguard and Phonelock password. Contact your service provider for details.

Safeguard Mode

In the safeguard mode, the Call list, Contacts, Messages and Speed dial can be accessed only by entering a password.

To enter the safeguard password, select **Menu > Settings > General tab > Security settings > Safeguard**. Enter the password. After entering the password, the **private information** screen is displayed. Press the **menu** key to select the required features to be safeguarded and select **OK** to enable.

Phonelock Mode

In the phonelock mode, the phone can be unlocked only by entering a password.

To enter the phonelock password, select **Menu > Settings > General tab > Security settings > Phonelock > On**. Enter the password. Select **OK**.



The default password for safeguard and phonelock is **1234**.



To change the safeguard or phonelock password, select **Menu > Settings > General tab > Security settings > Change password > Change phonelock pw / Change safeguard pw**. Enter the password. Select **OK**. Enter the new password. Select **OK**. Reenter the new password. Select **OK**.

Auto Keypad Lock

To lock the keypad, select **Menu > Settings > General tab > Auto keypad lock**. You can choose to switch it off or enable the feature by setting time.

Alternatively press and hold the "*" key to lock and unlock the keypad.

Date and Time

To set the Date and Time, select **Menu > Settings > General tab > Date & Time**.





Silent Mode




In the silent mode, the alerts for Calls, Organizer, SMS and battery status are disabled.










Select **Menu > Settings > Sounds tab > Alert type > Silent** OR **press and hold** the # key.

Keypad Functions

The following table displays the various keys and the corresponding functions they perform:

Keypad key	Operations
 POWER ON/OFF/END CALL	<ul style="list-style-type: none">• Press to end a call (GSM).• Press and hold to switch on or switch off the mobile phone.• Press when in Menu or Edit modes to return to Standby mode.• Press to reject an incoming call.
 CALL/ACCEPT/SEND	<ul style="list-style-type: none">• Press to answer an incoming call.• After entering a phone number, press to make a call.• Press while in Standby mode to access All calls list.
 LSK/RSK	<p>These keys are present immediately below the display screen.</p> <ul style="list-style-type: none">• Press the Left Selection Key (LSK) or Right Selection Key (RSK) to select the function indicated at the bottom of the screen. The indicated functions can vary according to different program definitions.• Press LSK to access the main menu in standby mode.• Press RSK to access the Contacts in standby mode.
 MENU KEY (CENTRE)	<p>Present at the centre of the navigation keys.</p> <ul style="list-style-type: none">• Press while in standby mode to enter the main menu.• Press when required to be used as a toggle key to select or clear a checkbox.• Press to perform similar tasks as the Left Selection Key.• Press to select the OK command.

Keypad key	Operations
 <p data-bbox="75 389 239 415">NAVIGATION KEYS</p>	<p data-bbox="425 142 1307 215">The Left and Right Selection keys and Power On/Off keys surround this key group. There are arrows on the key that denote the direction to scroll for information displayed on the screen.</p> <p data-bbox="425 234 519 260">UP/DOWN</p> <p data-bbox="425 289 1009 314">Press to move the cursor up or down in the text editor.</p> <ul data-bbox="425 314 1212 408" style="list-style-type: none"> • Press to view the pages in the text editor. • Press to browse menus/lists at the same level. • Press to view the previous or next picture when previewing pictures. • Press to browse the main menu. <p data-bbox="425 426 537 452">LEFT/RIGHT</p> <p data-bbox="425 481 771 507">Press to navigate between tabs.</p> <ul data-bbox="425 507 1061 553" style="list-style-type: none"> • Press to move the cursor left or right in the text editor. • Press to browse the main menu.
<p data-bbox="75 705 285 731">ALPHA-NUMERIC KEYS</p>	<ul data-bbox="425 653 1282 798" style="list-style-type: none"> • Press the required keys to enter the desired phone number and press  to make a call. Alternatively, enter the number and select Option to dial the number. • Press and hold any numeric key to access the shortcut assigned, while in standby mode. • Enter text while in the text editor.
	<ul data-bbox="425 829 1117 875" style="list-style-type: none"> • Press and hold in standby mode to access your Voice mail. • When entering text, press to enter space.

Keypad key	Operations
	<ul style="list-style-type: none"> • Press and hold to launch Opera Mini.
	<ul style="list-style-type: none"> • Press and hold to launch Sonim Mail.
	<ul style="list-style-type: none"> • The shortcut for this key can be configured according to different requirements. The user can change the settings.
	<ul style="list-style-type: none"> • Press and hold to turn on the torch.
 to 	<ul style="list-style-type: none"> • The shortcut for these keys can be configured according to different requirements. The user can change the settings.
	<ul style="list-style-type: none"> • Press and hold to display '+' used for dialing an international number, while in standby mode. • When entering text, press to enter a dot (.).
	<ul style="list-style-type: none"> • Press and hold to lock the keypad. Use it as a toggle key to lock and unlock the keypad, while in standby mode. • When entering text, press to display special characters, for example, period, comma, and so on. Press and hold to display the text input languages.
	<ul style="list-style-type: none"> • Press and hold in standby mode to switch between Silent on/off modes. • When entering text, press to switch between lower case, upper case or numeric. Press and hold to enable T9 mode.


Your Sonim XP3.20 Phone

This model is a bar type phone with a single LCD screen. The graphic field of the screen is 176 (w) and 220 (h) pixels. The TFT technology used displays 64K colours.

Main Menu

To access the phone menu, press the **menu** key. The main menu which comprises the following nine items appears.

Main Menu Icons









1. CALLS
2. SETTINGS
3. MY FILES
4. PHONEBOOK
5. CAMERA
6. TOOLS
7. MESSAGES
8. APPLICATIONS
9. BROWSER









Home Screen Indicators







The home screen indicators are visible when the phone is in standby mode. Some icons indicate the status of certain functionalities of the phone, for example, the battery charge indicator, the network status indicator, the date and time etc. Some icons are displayed only if the specific service is activated.





The following table describes the display indicators on the top bar of the home screen in the Sonim XP3.20 phone. These icons depend on the selected theme.






Display Indicators	Name	Description
	Battery	Four clear bars indicate maximum battery charge. Opaque bars indicate decline in battery charge
	Roaming	This icon is only displayed when your phone is registered with a non home network.
 	GPRS	G displayed in green indicates that the phone is GPRS attached. G displayed in red indicates that GPRS is detached.
	Alarm Clock	Indicates that the alarm clock has been set.
	Meeting	Indicates that the phone is on meeting mode.

Display Indicators	Name	Description
	Call Forward	Indicates that the call forward function is enabled.
	Unread Message	Indicates that there are unread messages in the inbox.
	SMS Memory Full	Indicates that the SMS memory is full.
	Voice Message	Indicates a new voice message.
	Auto Answer	Indicates that auto answer has been set.
	Keypad Lock	Indicates that the keypad is locked.
	Firewall	Indicates that the black list/white list has been enabled.
	GPS	Indicates that GPS is turned on.





Display Indicators	Name	Description
	Bluetooth Connectivity	Indicates that bluetooth is active.
	Bluetooth CarKit/Headset Connectivity	Indicates that your device is paired and connected to a carkit or headset with bluetooth connectivity.
	Micro SD Card	Indicates that Micro SD card is inserted.
	WAP Push Message	Indicates a new WAP push message.
	Wired Headset	Indicates that a wired headset is connected.
	Both Vibration and Ringing	Indicates that the phone performs both vibration and ringing.

Display Indicators	Name	Description
	EDGE	Indicates that the packet data session is active and EDGE feature is available in the cell.
	GPRS	Indicates that the packet data session is active and GPRS feature is available.

The following table describes the display indicators on the GSM call screen in the Sonim XP3.20 phone:

Display indicators	Name	Description
	Active Call	Indicates an active call.
	Call on Hold	Indicates a call on hold.
	Call on Mute	Indicates a call on mute.
	Handsfree Call	Indicates a handsfree call.
	Active Conference Call	Indicates an active conference call.

The following table describes the display indicators on the home screen in the Sonim XP3.20 phone:

Display Indicators	Name	Description
	Incoming Call	Indicates an incoming call.
	Outgoing Call	Indicates an outgoing call.
	Missed Call	Indicates a missed call.
	Missed Appointment	Indicates a missed appointment.

- My files
- Camera
- Tools
- Applications

Key Operations without Your SIM Card

Menus Accessible

The following menus can be accessed on the phone without the SIM card:

- Settings
 - General settings
 - Display settings
 - Sounds settings

Phone Settings

You can activate and modify various settings on your Sonim XP3.20 phone. On the home screen, select **Menu > Settings** to display the options.

General Settings

Select **Menu > Settings > General tab**. The following general settings are displayed.

Profiles

You can customise the profiles to use features such as ring volume, alert type, key sound and back-light level. There are seven environment profiles present in this phone. Personal is the default profile, while the other profiles are Car, Flight, Home, Meetings, Outdoor and Silent.



You cannot change the parameters for the Flight and Silent modes.

- **Personal:** This is the default profile where all sounds are enabled. Parameters in this mode can be changed. Select **Menu > Settings > General tab > Profiles > Personal > Option > Personalize** to open the Personalize screen. You can use this screen to choose ring volume, alert type, key sound or backlight level. Select **Menu > Settings > General tab > Profiles > Personal > Option > Activate** to activate this profile.
- **Car:** Parameters in this mode can be changed. Select **Menu > Settings > General tab > Profiles > Car > Option > Personalize** to open the Personalize screen. You can use this screen to choose ring volume, alert type, key sound or backlight level. Select **Menu > Settings > General tab > Profiles > Car > Option > Activate** to activate this profile.

- **Flight:** Here all sounds are kept in mute. Select **Menu > Settings > General tab > Profiles > Flight > Option > View** to open the View screen. Select **Menu > Settings > General tab > Profiles > Flight > Option > Activate** to activate this profile. In this mode, the phone cannot make or receive calls or play FM radio.
- **Home:** Parameters in this mode can be changed. Select **Menu > Settings > General tab > Profiles > Home > Option > Personalize** to open the Personalize screen. You can use this screen to choose ring volume, alert type, key sound or backlight level. Select **Menu > Settings > General tab > Profiles > Home > Option > Activate** to activate this profile.
- **Meetings:** Here only the vibrate mode is enabled. Parameters in this mode can be changed. Select **Menu > Settings > General tab > Profiles > Meetings > Option > Personalize** to open the Personalize screen. You can use this screen to choose ring volume, alert type, key sound or backlight level. Select **Menu > Settings > General tab > Profiles > Meetings > Option > Activate** to activate this profile.
- **Outdoors:** Here both the vibrate and ring modes are enabled. Parameters in this mode can be changed. Select **Menu > Settings > General tab > Profiles > Outdoors > Option > Personalize** to open the Personalize screen. You can use this screen to choose ring volume, alert type, key sound or backlight level. Select **Menu > Settings > General tab > Profiles > Outdoors > Option > Activate** to activate this profile.
- **Silent:** Here all sounds are kept in mute. Select **Menu > Settings > General tab > Profiles > Silent > Option > View** to open the View screen. Select

Menu > Settings > Profiles > General tab > Silent > Option > Activate to activate this profile.



Alarm tone will be played even in Silent profile.

Languages

You can change the phone's interaction language by selecting your preferred language. For example, select **Menu > Settings > General tab > Languages > English** to display all menu items, user feedback messages and text entry language in English.

Time and Date

You can set and display the date and time on the phone. You can also select the display format. The time zone can also be set for local settings and foreign settings.



The date formats supported are YYYY/MM/DD, YYYY-MM-DD, YYYY.MM.DD, DD/MM/YYYY, DD-MM-YYYY, DD.MM.YYYY, MM/DD/YYYY, MM-DD-YYYY or MM.DD.YYYY. The time formats supported are 24 hr and 12 hr.

You can view the time of major cities in different time zones using this function and set the time on your phone to a selected time zone. You also have the option to use Daylight Saving Time (DST).

The local time or the international time is displayed in the lower half of the screen. Use the navigation keys to view various time zones.

1. To view the international clock, select **Menu > Settings > General tab > Date and Time > International clock > Clock status > On**. The international clock is displayed on the idle screen.

2. To set your local time, select **Menu > Settings > General tab > Date and Time > International clock > Local settings > Option > Set time > Change time**. Enter the time and select **OK**. To set the local date, select **Option > Set time > Change date**. Enter the date and select **OK**.
3. To set Daylight Saving Time (DST), select **Menu > Settings > General tab > Date and Time > International clock > Local settings OR Foreign settings > Option > Daylight saving > On**.
4. To switch between local and foreign settings, select **Menu > Settings > General tab > Date and Time > International clock > Switch local/foreign > OK**.
5. To view the city list, select **Menu > Settings > General tab > Date and Time > International clock > Local settings OR Foreign settings > Option > City list**.
6. **Auto Update:** This feature allows the phone to automatically adjust the time to the time and date details sent by the network. Please note that this feature has to be supported by the network. The following options are available for the user:
 - **Always:** Whenever the time and date information is received from the network, the phone adjusts its time and to that value.
 - **Never:** The phone ignores the time and date information sent by the network
 - **While not roaming:** The phone adjusts the time automatically, only if it is operating in home network.

Security Settings

To prevent unauthorised use of your phone, you can set PIN protection, safeguard and phonelock. To enable PIN protection or phonelock, select **On**. To enable safeguard, enter the password. To change any security related password, select **Change Password** and change the particular password. The default password for phonelock and safeguard is 1234. For the PIN, please contact your operator.

Shortcuts

Shortcut keys have been set for specific functions. To activate a shortcut, select the shortcut and select **Option > Activate**. To change any shortcut, select the shortcut and select **Option > Change**. Select the new function. There are two tabs, one for numeric keys and the other for navigation keys.

Default Storage

The individual storage location for Camera, Voice recorder, WAP download or Bluetooth can be set as Phone memory or Memory card. By default, it will be Phone memory.

Memory Status

The memory status for Contacts, Messages, My files and Memory card is displayed.

Auto Power On

To enable this feature, select **On**. Select the time after which the phone should be automatically switched on. Select **OK**. Select **Off** to disable this feature.

Auto Power Off

To enable this feature, select **On**. Select the time after which the phone will be automatically switched off. Select **OK**. Select **Off** to disable this feature.

Firewall

You can avoid unwanted calls or messages by entering such numbers in the Black list and enabling the Black list. You can receive calls or messages only from specific numbers by entering such numbers in the White list and enabling the White list. You can enable either the Black list or White list at a time.

1. To enable the Black list or White list, select **Menu > Settings > General tab > Firewall > Enable > Black list OR White list > SMS OR Incoming call OR SMS and Incoming call > OK**.
2. To disable the Black list or White list, select **Menu > Settings > General tab > Firewall > Enable > Off**.
3. To enter a number in Black list or White list, select **Menu > Settings > General tab > Firewall > Black list OR White list > Add new > New number (enter the number) OR Contacts (select the number from Contacts) > OK**.

Auto Keypad Lock

Select the time after which the keypad will be automatically locked. Select **Off** to disable this feature. The keypad should be locked automatically when the phone is in idle state on home screen.

Default Settings

Select to reset the settings to the original factory settings. Please note that this can remove changes you have made to your settings.

Display Settings

Select **Menu > Settings > Display tab** . The following display settings are displayed:

1. **Wallpaper:** Allows you to set the background screen display using the embedded pictures available in your phone or from your own pictures that you have downloaded on to your phone or Micro SD card. The selected wallpaper is displayed on the home screen only if you select **On**.
2. **Themes:** Allows you to set the colour theme and icons for the main menu and other screens. There are two themes available. Select **Menu > Settings > Display tab > Themes > Theme 1 OR Theme 2 > OK**.
3. **Backlight Level:** Select the backlight level of the screen display as maximum, high, medium or low.
4. **Backlight Duration:** Keeps the screen display active for the period chosen by you. Select the screen display active time as 10 sec, 30 sec or 60 sec.
5. **Greeting:** Select **On**. Enter the greeting and **Save** to make it appear on the screen while powering on the phone.
6. **Screensaver:** Select **On** to make the screen saver appear on the idle screen. User can select the screensaver image.

Sound Settings

Select **Menu > Settings > Sounds tab** . Changing it effects the current set profile. The following sound settings are displayed:

1. **Alert Type:** You can set the alert type for incoming calls and SMS alerts. You can select from Ring only, Vibrate only, Vibrate then Ring, Ring and Vibrate or Silent.
2. **Ringtone:** You can set different ringtones for your calls., SMS alerts, alarms, organizer and calendar. You can select from Default sounds (pre-recorded factory tunes) OR Phone memory (downloaded via WAP, personal recordings or files transferred via Bluetooth) OR Memory card.



You can download and store ring tones over Bluetooth or WAP. The ringtone formats are MIDI, MP3, WAV, AAC and AMR.

32

3. **Ringer Volume:** You can set the ringer volume for GSM calls, alarms and alerts.
4. **Key Tone:** You can set the keypad sound as Off, Low, Medium or High.
5. **Shutter Sound:** You can set the camera shutter sound.
6. **Battery Alert:** Select **On** to get any low battery alert.

Connectivity Settings

Select **Menu > Settings > Connectivity tab**. The following connectivity settings are displayed:

- 1. Network Settings:** This relates to various network related settings. You can select your network, specify the network account, indicate whether GPRS is required at all times, and so on.
 - **Select Network:** Your phone will select the network automatically or you can do it manually.
 - **Search Mode:** You can select **Auto** to set the phone to automatically select a cellular network available in your area, or select **Manual** to set the network manually. If manual mode is set, the user has to invoke **Select Network** to do network selection.
 - **Preferred Networks:** You can view the list of networks. Select **Option to Insert, Add to end, Add existing, Add network code** or **Delete**. This list is made to use while the user is roaming.
 - **Attach GPRS:** You can access the GPRS network. Enables you to choose the registration preference.
 - **GPRS Info:** You can view the GPRS information such as data received, when used as a modem.
- 2. Connections:** You can set the Network account and view the GPRS information.
 - **Network Account:** You can view or edit the accounts. There are five accounts present. You can edit the following information in the accounts: Account name, APN, Login and Password. Make the changes and select Save.



When **Always attached** is selected, the phone always remains registered with the GPRS network.




When **Attached during PDP session** is selected, the phone gets registered with the GPRS network only when data transfer is required.

Calls

This section provides information on managing calls.

Dial a Number

1. Use the numeric keys to enter the number and press .
2. Alternatively you can enter the desired phone number and select **Option > Dial > Dial > Select**.



Dial an International Number

Press and hold the numeric key 0 till the + symbol is displayed. Enter the Country code, Area code (without preceding 0) and the phone number and press  or select **Option > Dial > Dial > Select**.

Dial a Number via Contacts



You can dial a number directly from the Contacts.

To Locate a Phone Number

1. On the home screen, select **Contacts**. Scroll to the phone number.
2. Press  to dial the number OR select **Option > Dial > Dial > Select** OR press the **easy call** key. Press  or Select **End** to disconnect.

Dial a Number via the Calls List

The Calls list comprises separate lists for All calls, Missed calls, Answered calls and Outgoing calls.

1. To access the Calls list, press  OR select **Menu > Calls > Call list**. All the available call lists are displayed.
2. Select a list, scroll to the number and press  to dial the number.

Managing Call List

Contacts within the call list have the following options:

- **Save:** You can save the number in Contacts (if it is not saved).
- **Send messages:** You can send an SMS to the number. Enter the SMS and select **Option** to view the SMS options and send it accordingly.
- **Send phone number:** You can send the name and phone number of a contact to the recipient via SMS.
- **Delete:** You can delete the number from the Call list.
- **Dial:** displays dial options from which to choose.


Dial Dials the selected number.

Handsfree Dial You can talk using the speaker.



-
- **Add to blacklist:** You can add the number to blacklist.
 - **Edit number before dialing:** You can edit the number before dialing.

Speed Dial

This option enables you to dial a number quickly via a shortcut.

1. If shortcut is not set for Speed dial, select **Menu > Settings > General tab > Shortcuts > scroll to a key > Option > Change**. Select Speed dial from the list. The shortcut is set.
2. Press and hold the shortcut designated for Speed dial from home screen. The Speed dial screen appears.
3. To add a new contact, scroll to an empty slot, select **Add**. Select the contact. Select **Yes** to add a picture or **No** to not add picture. Select the picture from Default pictures OR Phone memory OR SD card. The Speed dial is set.
4. To make a call, press . The other options available for a contact are View, Replace, Delete and Send message.

Receive a Call

1. To receive a call, press the **Accept** key  OR press **Left Selection** key. Select **Accept**.
2. To reject a call press the **Power on/off** key  OR press **Left Selection** key. Select **Reject**.
3. To receive another call while you are already speaking, enable the call waiting feature for GSM calls. Select **Menu > Calls > Call settings > Call services > Call waiting > Enable**.

Auto Answer

When auto answer is enabled, your incoming calls will automatically be answered.


Select **Menu > Calls > Call settings > Auto answer > On**.

Anykey Answer

When enabled, you can press any key except  to answer a call.

To activate this feature, select **Menu > Calls > Call settings > Anykey answer > On**.



Long pressing (press and hold) the Power on/off key  during a GSM call will only end the call and not switch off the phone.

Minute Reminder

When enabled, you receive a prompt at the 45th second of every minute during a conversation. Select **Menu > Calls > Call settings > Minute reminder > On**.

Call Services

Call Time

- To view the total time spent on the last call, select **Menu > Calls > Call settings > Call services > Call time > Last call**.
- To view the total time spent on incoming calls, select **Menu > Calls > Call settings > Call services > Call time > Incoming call**.

- To view the total time spent on outgoing calls, select **Menu > Calls > Call settings > Call services > Call time > Outgoing call**.
- To view the total time spent on all calls, select **Menu > Calls > Call settings > Call services > Call time > All call time**.

Call Waiting

When call waiting is enabled and your phone is in conversation, the message **Call waiting** and the number is displayed when you receive an incoming call.

- To enable this facility, select **Menu > Calls > Call settings > Call services > Call waiting > Enable**.
- To cancel this facility, select **Menu > Calls > Call settings > Call services > Call waiting > Cancel**. You will not be prompted when you receive an incoming call while your phone is busy. The caller will receive a busy signal.
- To verify the call waiting status, select **Menu > Calls > Call settings > Call services > Call waiting > Status**.

Own ID

When enabled, your ID is displayed to the recipient when you call or send a message. However this service must be supported by your network.

- To enable this option, select **Menu > Calls > Call settings > Call services > Own ID > Show ID**.
- To disable this option, select **Menu > Calls > Call settings > Call services > Own ID > Hide ID**.
- To request the network to set this option, select **Menu > Calls > Call settings > Call services > Own ID > Set by network**.

Caller ID


When enabled, you can view the ID of the caller. To enable this option, select **Menu > Calls > Call settings > Call services > Caller ID**.

Call Forwarding

You can forward your incoming calls to a number in the Contacts or a new number, provided your network operator supports this service. To access call forward settings, select **Menu > Calls > Call settings > Call forward**. The Call forward options are mentioned below:

Call Forward Option	Function
All calls	Forward all incoming calls to a pre-designated number.
If no reply	Forward calls when you do not answer incoming calls.
If unreachable	Forward calls when you have switched off your phone or you are out of network coverage area.
If busy	Forward calls when your phone is busy.
Status	Check the current Call forward status.
Cancel all	Deactivates the call forward option.



When All calls divert is enabled, the icon  is displayed at the top of the screen when the phone is in standby mode.

Call Barring

You can set Call barring facility for all outgoing calls, outgoing international calls, local and home only, all incoming calls or roaming incoming calls.

1. To set call barring settings, select **Menu > Calls > Call settings > Call barring**.
2. Enter the restriction password. (Your network operator provides this before you use this function). This password will be sent to the network for verification.

The Call barring options are mentioned below:

Call Barring Option	Function
All outgoing calls	All outgoing calls are barred.
Outgoing international calls	All international calls are barred.
Local and home only	Subscriber can make calls to mobile or landline phones in the country where the subscriber is currently located and to the home country of the subscriber. The home country is the location of the SIM card's provider.
All incoming calls	All incoming calls are barred.

Roaming incoming calls	All incoming calls, while roaming abroad, are barred.
Barring status	Checks the current call barring status.
Cancel all	Deactivates call barring.

Fixed Number Dialing

A fixed set of numbers are stored as fixed numbers and only those numbers can be dialed from the phone. User(s) can make calls from Contacts or dial the number if the selected number is stored in fixed numbers list. User(s) can however receive calls from any number. User(s) cannot make calls to the numbers which are not stored in fixed numbers list.

1. Select **Menu > Calls > Call settings > Fixed Dial > Mode > On**. Enter the PIN2 to activate fixed number³⁷ dialing.
2. Enter the PIN2 to activate fixed number dialing. Select **Add new** to add a new number to the list or select Fixed numbers list to view the list.



For your PIN2, please contact your service provider.

Auto Redial

When auto redial is enabled, your phone will automatically redial within a set interval, if a call does not connect.

1. To enable this function select **Menu > Calls > Call settings > Auto redial > On**.
2. If the attempt to call is not successful, you will be prompted with the message **Auto redial?** Select **OK** to redial. Select **Back** to return to home screen.

Filter Calls

This function enables you to avoid receiving unnecessary calls OR messages. Users can select SMS/Calls/Both SMS and Calls to go to the black list/white list.



At any point of time, you can enable either black list or white list. If white list is enabled, only the contacts in the white list can reach you. When black list is enabled, all other contacts except the ones in the black list can reach you.

To enable this function, select **Menu > Settings > General tab > Firewall > Enable > Black list or White list > SMS or Incoming call or SMS and Incoming call > OK**.



If the black list or white list is empty, it cannot be enabled.

- **Enable Black list:** Rejects all incoming calls and messages from numbers in the black list.

- **Enable White list:** Allows incoming calls and messages from numbers in the white list and rejects incoming calls and messages from numbers that are not in the white list.
- **Off:** Disallows filtering of incoming calls and messages.

Add to Black list

To add a number to the black list, select **Menu > Settings > General tab > Firewall > Black list > Add new**. Two options are displayed:

- **New number:** You can enter a new number to be stored in the black list.
- **Phonebook:** You can open the Contacts list to select and transfer a number to the black list.



We can add a maximum of 50 numbers to the blacklist.

Add to White list

To add a number to the white list, select **Menu > Settings > General tab > Firewall > White list > Add new**. Two options are displayed:

- **New number:** You can enter a new number to be stored in the white list.
- **Phonebook:** You can open the Contacts list to select and transfer a number to the white list.

Recording a Call

1. While making a call or receiving a call, you can **press and hold** the menu key to record or stop. Select **Option > Record > Record own voice** OR **Record opposite party** OR **Record both**.
2. A square button at the bottom indicates that recording is going on.
3. Select **Option > Stop** recording to stop the recording.
4. The recorded file is saved in the location **My files > Sounds**.

Depending on the settings, the storage location can be phone or Memory card.

Managing Contacts

You can use the Contacts list to maintain phone numbers of your contacts. This feature enables you to add, delete, dial phone numbers and send SMS messages. To access the contacts, select **Menu > Phonebook > Contacts**. The contacts are displayed.



You can use the **volume** keys to scroll through the contacts.

Add a New Contact

- To add a new contact, select **Menu > Phonebook > Contacts > Add new**. Press the menu key. Enter the name and phone number and select **Save**.
- Alternatively, you can directly enter a number and select **Option > Save**. Enter the name of the contact and select **Save**.

The new number is updated in the Contacts list.



If **Phone** is selected as the storage location, then the user can add many details apart from the name and phone number.

Dialing a Number from Contacts

On the home screen, select **Menu > Phonebook > Contacts**. Select the contact. Do one of the following.

- Select **Option > Dial > Dial OR Handsfree dial** (to talk using the speaker).
- Press the **easy call** key.

Sending a Message from Contacts

1. On the home screen, select **Menu > Phonebook > Contacts**. Select the contact. Select **Option > Send message**.
2. Enter the message and select **Option > Continue**.
3. Select **Send message** to send your message.

Add a New Contact in Group

On the home screen, select **Menu > Phonebook > Groups**. Select the group. Select **Add member**. The phone numbers in Contacts are displayed. Select the phone numbers to be added to the group.



Only the contacts stored in phone memory can be added to the group.

Group Settings

To view or change the group settings, select **Menu > Phonebook > Groups**. Select the group. Select **Option**. The following options are displayed:

- **View:** You can view the contacts in the group.
- **Rename:** You can rename the group. Enter the new group name. Select **OK** to save.
- **Send message:** You can send a message to the contacts in the group.
- **Reset:** You can reset the group settings.

Special Numbers

You can store some special purpose phone numbers in this location. It has three categories:

- **Own Info:** You can manage your own information. Select **Menu > Phonebook > Special numbers > Own info**. The following sub-menus are present.
 - **Edit own info:** Enter your Name and other personal details such as Mobile number, Office number, Home number, Fax number, Email, Postal address and Postal code. Select **Save**.
 - **Delete own info:** You can delete your information.
 - **Send own info:** You can send your information to any number via SMS.
 - **Display own info:** You can view your own information.
- **Service Numbers:** Contains the service numbers provided by the operator.
- **Voice Mail Number:** You can enter and save your voicemail number.

Default Contact List

1. Select **Menu > Phonebook > Advanced > Choose contact list > Default contact list**.
2. Select **Phone** or **SIM** or **All** to select the default contact list displayed.

Default Contact Location

1. Select **Menu > Phonebook > Advanced > Choose contact list > Default contact location**.
2. Select either **Phone** or **SIM** as the memory location to store the new numbers.

Sending Contact

You can send contact information by SMS or by Bluetooth.

Send Contact by SMS

1. Select **Menu > Phonebook > Contacts**.
2. Select the contact and select **Option > Send contact > via SMS**.
3. Enter the message and select **Option**.
4. Select **Contacts** to add existing phone numbers OR Select **Select multiple** to send the message to more than one number OR Select **Phone number** to enter the number.
5. Select **Send message** to send the contact in your message.

Send Contact by Bluetooth

1. Select **Menu > Phonebook > Contacts**.
2. Select the contact and select **Option > Send contact > via Bluetooth**.
3. If Bluetooth is not on, the user will get a prompt to turn it on.
4. Select the paired device to which you want to send the namecard.
5. If the device is not paired, select **Search more...** and then select the device.
6. When the other device accepts the contact, **Object sent** message will be displayed.

Delete Contacts

- To delete a contact, select **Menu > Phonebook > Contacts**. Select the contact and select **Option > Delete**.
- To delete all contacts, select **Menu > Phonebook > Advanced > Delete all contacts > Delete SIM records OR Delete phone records** > A message appears **Do you really want to delete all?** Select **OK** to delete (if the default contact list is **All**)
OR
Select **Menu > Phonebook > Advanced > Delete all contacts**. A message appears **Do you really want to delete all?** Select **OK** to delete (if the default contact list is **Phone OR SIM**).

Copy or Move Numbers between Phone and SIM

- To copy all records from Phone memory to SIM card, select **Menu > Phonebook > Advanced > Copy to SIM > select > OK**.
- To copy all records from SIM card to Phone memory, select **Menu > Phonebook > Advanced > Copy to phone > select > OK**.
- To move all records from Phone memory to SIM card, select **Menu > Phonebook > Advanced > Move to SIM > select > OK**. Moved records get deleted from the source location. All the records moved from the Phone memory will not be available in the Phone memory thereafter.
- To move all records from SIM card to Phone memory, select **Menu > Phonebook > Advanced > Move to phone > select > OK**. Moved records get deleted from the source location. All the records moved from the SIM card will not be available in the SIM card thereafter.

Adding a Contact to Blacklist

1. Select **Menu > Phonebook > Contacts**.
2. Select the contact and select **Option > Add to blacklist**.

Adding a Contact to Whitelist

1. Select **Menu > Phonebook > Contacts**.
2. Select the contact and select **Option > Add to whitelist**.

Searching Contacts

1. Select **Menu > Phonebook > Contacts**.
2. Enter the contact name.
3. The contact will be displayed.

Messages

SMS is a convenient and inexpensive means of communication. You can send a text message to other people via this service. You can use the Messages menu in your phone to send an SMS message to other mobile phones or any other equipment that can receive SMS. To access the SMS function select **Menu > Messages**. The list of options are displayed.

Advanced Settings

To view or define settings for your messages select **Menu > Messages > Advanced**.

- **Cell info:** You can select to receive broadcast messages.
 - **Reception:** Select **On** to get information about the reception tower.
 - **Topics:** Select **Topics > Add new** to add the channel number of the topic to get information.
- **Message settings:** You can set the SMS account. Select **SMS Account > Option > Activate** to set selected account. Select **SMS Account > Option > Edit** to edit the following settings:

Settings	Function
Service Center No	The message centre number, provided by your service provider, via which your messages are sent. The phone automatically picks up this number if it is already configured in the SIM card
Validity period	Select the period for which your messages will be stored in the message centre.

Status report	Select On to get a confirmation report whether message has been delivered or not.
Signature	Select On to set a signature that will be attached along with your sent messages.
Storage location	Select SIM or Mobile phone as the storage location of messages.
Send & save	Select On to save the sent messages.

- **Memory status:** You can view the number of messages stored in the SIM and the mobile phone.
- **My favourites:** You can view the messages stored in this location.
- **SIM archive:** You can view the messages stored in the SIM.
- **SMS timer:** You can add a timer to an SMS and mention the time in which it is to be sent. Select **SMS timer > Add > Enter the text > Save > Contacts or Phone number > Enter date > OK > Enter time > OK**. The user is prompted when it is time to send the SMS.

Text Input Mode

When you enter text, the input mode is displayed at the top left of the screen. Press and release the # key to view the different text input modes, that is conventional (Abc/ABC/abc) and numeric (123). **Press and hold** the # key to enable the T9 mode.

In conventional mode, you can enter a letter by repeatedly pressing a key until the letter you want appears. Numeric mode is used to input numbers.

In T9 mode, when you press a key, the alphabets or letters are displayed. Scroll to the alphabet or letter and press the **menu** key to select.

- To switch between upper case (ABC), lower case (abc) or sentence case (Abc), use key **#**. When the sentence case is used, the letter which comes immediately after the characters full stop (.), exclamation mark (!) and question mark (?) automatically becomes capital.
- To enter a character, press the numeric key repeatedly until the desired character appears on the screen. For example, to enter GOOD, in the text mode, press **4** once to display G, press **6** thrice to display O, and again press **6** thrice to display O and press **3** once to display D.
OR
If you are in T9 mode, press **4** once. Press **6** twice. Press **3** once, scroll to and select GOOD.
- When editing text, to insert a space between characters or words, press **1**.
- To erase a character select **Clear**.
- Press **0** to insert a full stop(.).

To insert special characters, press ***** to display the special characters. Press the **navigation keys** to scroll through the special characters. Select the character to appear in the text.

Press and hold * to display the text input in different languages. Press the **menu** key to select the language. Select **Done** to change the text input language.

Write Messages

- To create a message select **Menu > Messages > Create message** OR press the **Right navigation key** as a shortcut to the Write message screen.

- Enter the message in the text pane. The text input mode is displayed at the top left of the screen. Press and release **#** to select the appropriate text input mode.
- Enter the message and select **Option**. The following options are present:

Option	Function
Contacts	You can select the number from Contacts.
Select multiple	You can select more than one number from Contacts. Use the menu key to select.
Phone number	You can enter the phone number.
Group	You can send the message to a group.
Use template	You can use a message template stored in Templates folder.
Save as draft	You can save the message as a draft in Draft folder.
Save as template	You can save the message as a template in Template folder.



Instead of selecting **Option**, press the **menu** key to quickly send the message to a number in Contacts.

- Select **Send message** to send the message OR select **Add recipient** to add another recipient.

Send a Message via Contacts

You can send an SMS from the Contacts.

1. On the home screen, select **Menu > Phonebook > Contacts**. Select the contact. Select **Option > Send message**.
2. Enter the message and select **Option > Continue**.
3. Select **Send message** to send the message OR select **Add recipient** to add another recipient.

Call or Save a Number Embedded in a Received Message

It is possible to call a number embedded in a received SMS.

1. Select **Menu > Messages > Inbox** > open the message containing numbers.
2. Select **Option > Save number**. The number is displayed.
3. Select **Option > Dial** OR Select **Option > Save**.

Manage Your Messages

The inbox, outbox, sent and draft folders displays the number of stored messages in parenthesis.

Inbox

The Inbox stores and displays all the incoming messages.

1. To access the Inbox, select **Menu > Messages > Inbox > Select**. The Inbox displays a list of messages.
2. Scroll to a messages and select **Option** to view the following list of options.

- **View:** You can view the message.
 - **Reply:** You can send a message to the sender of that message.
 - **Forward:** You can send the message to another recipient.
 - **Delete:** You can delete the message after reading it.
 - **Delete all:** You can delete all the messages.
 - **Save number:** You can save the numbers present in the message. You can also dial or send a message to the numbers (this option is displayed only if the SMS text contains any number).
 - **Archive to SIM:** You can save the message in your SIM card memory (this option is displayed only if the SMS storage location is Mobile phone).
 - **Move to favourites:** You can save the message in My favourites folder. These will be stored in the phone memory.
 - **Details:** You can view the details about the message such as storage location and time of receipt.
 - **Dial:** You can call the sender of the message.
 - **Smart search:** You can search for a message based on the **Name, Number** or **Time**.
 - **Select multiple:** You can select the messages one by one or select all the messages at one go.
3. To open a message, scroll to a message and press the **menu** key.
 4. After a message is opened other functions can be performed. Select **Option** to list the following options: **Reply, Forward, Delete, Save number, Move to favourites, Details** and **Dial**.

Outbox

Messages that were undelivered to the recipient due to some reason are stored in Outbox.

1. To access undelivered messages, select **Menu > Messages > Outbox**.
2. Select **Option** to display the outbox options.
3. Press the **menu** key to view the message.
4. Press **Option > Resend** to send the message. You can also forward an undelivered message.

Draft Messages

Messages that have been saved to be sent later are stored in Draft.

1. To access unsent messages, select **Menu > Messages > Draft**.
2. Select **Option** to display the draft options.
3. Press the **menu** key to view the message.
4. Press **Option > Send** to send the message.

Sent Messages

Messages that have been sent and delivered are stored in Sent.

1. To access sent messages, select **Menu > Messages > Sent**.
2. Select **Option** to display the sent options.
3. Press the **menu** key to view the message.
4. Press **Option > Resend** to resend the message.
5. You can also forward a sent message.

Predefined Messages

You can customise and store up to a maximum of 10 messages in Templates.

1. Select **Menu > Messages > Templates > Select > OK**.
2. Enter a message and select **Option > Save Templates**.

View SMS Memory

To view the memory capacity for messages, select **Menu > Messages > Advanced > Memory status**.

Voice Mail

Your incoming calls can be forwarded to your voice mail. Callers will be prompted to leave a message for you. This feature requires you to enter a voice mail number which is provided by your service provider. 46

1. To set voice mail number, select **Menu > Messages > Voice mail > Voice mail number > Select**. Enter the number provided by your service provider. Select **Save**. This number should be used when you want to listen to your stored voice mail messages.
2. When you need to listen to your incoming voice mail messages, select **Menu > Messages > Voice mail > Call voice mail > Select**. Enter your voice mail number and select **OK**. You are connected to your mailbox where you can hear the stored voice mails messages. If your voice mail number is already stored, select **Menu > Messages > Voice mail > Call voice mail > Call**.



For quick access to voice mail, press and hold **1**.

SIM Card Menu

You can access certain services provided by the operator using this menu. This feature can be accessed via **Menu > Messages > Operator service**.

Hardcoded Shortcuts

The following are a set of special shortcuts related to voice calls. Some of these features may require network support.

- Enter 0 followed by SEND - releases all held calls or sets User Determined User Busy (UDUB) for a waiting call.
- Enter 1 followed by SEND - Releases all active calls (if any exist) and accepts the other (held or waiting) call.
- Enter 1X followed by SEND - Releases a specific active call X.
- Enter 2 followed by SEND - Places all active calls (if any exists) on hold and accepts the other (held or waiting) call.
- Enter 2X followed by SEND - Places all active calls on hold except call X with which communication shall be supported.
- Enter 3 followed by SEND - Adds a held call to the conversation.
- Enter 4 followed by SEND - Connects two calls and disconnects the subscriber from both calls (ECT).
- Enter 4 * "Directory Number" followed by SEND - Redirects an incoming or a waiting call to the specified directory number.
- Enter 5 followed by SEND - Activates the completion of calls to busy subscriber request.
- Enter "Directory Number" followed by SEND - Places all active calls (if any exists) on hold and sets up a new call to the specified directory number.
- Enter END - Releases the subscriber from all calls (except a possible waiting call).



"X" is the numbering (starting with 1) of the call given by the sequence of setting up or receiving the calls (active, held or waiting) as seen by the served subscriber. Calls hold their number until they are released. New calls take the lowest available number.



Where both a held and a waiting call exist, the above procedures shall apply to the waiting call (that is, not to the held call) in conflicting situation.

WAP Browser

This mobile phone has an internal WAP browser that allows you to browse contents of various WAP websites on the Internet. This facility is made available only if you subscribe to a data service from your network operator for Internet access. You need to consult your local operator for more details. Configure the WAP when you use it for the first time. Some WAP parameters on your phone have already been set to a specific network operator. If you utilize the services of the same network operator you can directly operate the WAP service with the available configuration. If not, you need to reconfigure the settings.



If you are unable to view WAP web pages because of change in WAP parameters or change in WAP web address or contents, please consult your network operator and Internet Content Provider (ICP) for updates.

Select **Menu > Browser > Select**. The following sub menus are displayed:

- **Load Homepage:** This is the page that is displayed first when you open the WAP browser.
- **Bookmarks:** You can use this menu to add and manage your bookmarks and go directly to the corresponding web address. You can also edit or delete bookmarks via this menu.
- **History:** You can view web pages which you have viewed previously. Click on them to open the pages.
- **Enter address:** You can enter a web address directly and browse.
- **Settings:** The following configurations can be set via this menu:
 - **Edit homepage:** You can edit the web address of your homepage. Specify a title and the web address.
 - **Select profile:** In this menu, existing profiles are listed on the display. Scroll to the required profile and select **OK**.
 - **Connection:** Specify the connection details for WAP. The following details are present:
 1. **Network account:** Select the profile which you had selected in **Settings > Connectivity > Connections > Network account**.
 2. **Connection type:** Select the connection type.
 3. **Timeout:** Enter the time (in seconds) after which your connection will be timed out.
 4. **Proxy address:** Enter the proxy address.
 5. **Proxy port:** Enter the proxy port number.
 - **Browser options:** You can enable the refresh option to refresh the web pages, you can select to display or not display images in the web pages and you can enable, disable or clear the cookies and the cache.
 - **Rename profile:** You can specify a name for the selected profile in this menu. The maximum length of the name is 40 characters.
 - **Push settings:** You can decide to receive or not receive push messages from operators and web portals.
- **Resume:** You can view web pages from where you last left off. Access the web pages you visited last via this menu. Select the Back and Forward options to move between web pages.
- **Push info:** This is the inbox for WAP push messages.

Opera Mini

Opera Mini is one of the most popular mobile web browsers. Opera Mini presents the users with rich and very fast web experience. The Sonim XP3.20 comes with a pre-bundled copy of Opera Mini.

Configuration of APN (Access Point Name) for Opera Mini

Set the network account for the Opera Mini.

1. Select **Menu > Settings > Connectivity tab > Connections > Network account > Select > Network A/c 5**. Select **Edit** to enter the profile details.
2. The following details are to be entered.
 - **Account name:** Enter the name of the account.
 - **APN:** Enter the access point name.
 - **Login:** Enter the login name.
 - **Password:** Enter the password.
3. Select **Save** to save the details.



Always use Network account 5 for Opera Mini and other Java applications.

Installation of Opera Mini

Select **Menu > Applications > Java > More Apps > Opera Mini.jad**. Install the application. Once Opera Mini is installed successfully, it will be displayed in the Java box.

Launching Opera Mini

Select **Menu > Applications > Java > Opera Mini**.

Java

Sonim XP3.20 has a collection of Java applications that are saved in the phone as default. You can also download more Java applications via WAP, Bluetooth, SD Card or Java Application Manager.

Installing Pre-bundled Java Applications

The phone has some of the following Java applications pre-bundled depending on your distribution. They can be installed by selecting **Menu > Applications > Java > More Apps**. You can find more applications in the Java Application Manager described below.

- **amAze GPS:** Makes the phone into a full featured GPS device with voice based turn-by-turn navigation.
- **Sonim Mail:** Provides email receiving and sending from the phone.
- **Java Application Manager (JAM):** This has an assorted list of applications that have been tested by Sonim on the phone. This picks up the latest list from a server over GPRS/EDGE.
- **Trimble Outdoors:** The popular complete personal assistant for trekking activities, now free with the phone.
- **Trimble AllSports:** Personal fitness assistant with calorie monitor, racing coach, and so on, now free with the phone.



In order to install the Java applications, the date and time must be set correctly on the phone.

Java Help

Select **Menu > Applications > Java Help**.

You will obtain information on how to install Java pre-bundled applications and how to set the APN.



Java applications can also be installed from the SD card.


Installing Java Application from SD Card

Select **Menu > My files > Memory card** tab. Select the file (.jar or .jad). The installation process begins. Once the application is installed successfully, it will be displayed in the Java box.

Installing Java Application from WAP

Configure WAP as described in “WAP Browser” on page 51 49. Launch WAP. Browse to the location where the file (.jar or .jad) is present. Select the file. The installation process begins. Once the application is installed successfully, it will be displayed in the Java box.



Some Java applications running in the foreground can be pushed to the background by pressing the  key.

Tools

This section contains miscellaneous features supported by the handset.

Alarm

You can set alarm for a particular time. Select **Menu > Tools > Alarm**.

1. To set a simple alarm, select **Menu > Tools > Alarm > Simple alarm**. Enter the time and select **OK**.
2. To set a recurrent alarm, select **Menu > Tools > Alarm > Recurrent alarm**. Enter the time and select **OK**. Using the **menu** key, select the day and select **Save**.
3. To set the alarm tone, select **Menu > Tools > Alarm > Alarm tone > Default sounds or Phone memory**. Select the alarm tone.
4. To enable snooze, select **Menu > Tools > Alarm > Snooze**. Use the **menu** key to toggle between on and off.



The alarm will work even if the phone is in Silent mode.



The alarm will work even if the phone is switched off.

Bluetooth

Bluetooth is a wireless connection that enables devices to exchange information. Devices within a range of 10 meters can be connected wirelessly using Bluetooth technology.

The Sonim XP3.20 is compliant with Bluetooth

specification 2.0 supporting the following profiles: Headset profile, Hands free profile, Object exchange profile, Dial up networking profile, Serial port profile. This device can send images and audio files using Bluetooth connection.



There may be restrictions on using Bluetooth technology in some locations. Check with your local authorities or service providers.

Activate Bluetooth

Select **Menu > Tools > Bluetooth > Activate**. Use the menu key to toggle between on and off. When Bluetooth is activated, the Bluetooth icon is displayed on the home screen.

Deactivate Bluetooth

Select **Menu > Tools > Bluetooth > Activate**. Use the menu key to toggle between on and off.

Bluetooth Settings

Type	Function
My name	Select this option to change the name of your device.
Visibility	Select On to show your presence to other devices. Select Off to hide your presence from other devices.
My profiles	Use this option to view the Bluetooth service list.

Pairing Devices

1. Select **Menu > Tools > Bluetooth > Search for devices**.
2. Select the device of your choice.
3. Enter the passcode (for example, **0000**) in the Enter passcode screen. The same passcode must be entered for the other device also.
4. Select **OK**.
5. When the other device accepts your request the message **Pairing Done** is displayed on the screen.
6. When the other device rejects your request the message **Pairing Failed** is displayed on the screen.



Do not pair with an unknown device for security reasons.

Connecting a Bluetooth Headset

You can connect a bluetooth headset after pairing it with your phone.

1. Select **Menu > Tools > Bluetooth > My devices**.
2. Select the paired Bluetooth headset.
3. Select **Option > Connect**.



For more details, refer the user manual of the Bluetooth headset.

Rename Paired Device

1. Select **Menu > Tools > Bluetooth > My devices**.
2. Select the paired device.
3. Select **Option > Rename**.
4. Enter the new name.
5. Select **OK**.

Delete Paired Device

1. Select **Menu > Tools > Bluetooth > My devices**.
2. Select the paired device.
3. Select **Option > Delete**.



If you cancel the pairing with a device that is connected, pairing is removed and the connection is switched off immediately.

Sending Data via Bluetooth

You can transfer files to another compatible device.

1. Select **Menu > My files**.
2. To send an image file, select **Pictures** > select the file OR To send an audio file, select **Sounds** > select the file OR To send any other file, select **Others** > select the file.

3. Select **Option > Send > via Bluetooth**.
4. Select the paired device to which you want to send the file.



My devices screen displays the paired devices. To send a data to an unpaired device, Select **Search more....** Select the unpaired device of your choice. Enter the pin code when you are asked to enter.

5. When the other device accepts your file, the message **Object sent** is displayed on the screen.
6. When the other device rejects the file, the message **Connection failed** is displayed on the screen.

Receiving Data via Bluetooth

To receive data using Bluetooth, your device should be Bluetooth activated and must be visible to other devices.

1. When you receive a data, you are asked if you want to accept it.
2. Select **Accept** to receive data OR select **Reject** to refuse the data.
3. If you accept, the data will be stored in **My files > Pictures** or **Sounds** or **Others**.

USB Function

You can transfer and synchronize data between the Sonim XP3.20 phone and your computer using either USB drive or PC Tools. Select **Menu > Tools > USB Function > USB Drive** OR **PC Sync**.



If you select USB drive, the SD Card should be present in the phone and the phone should be connected to the computer via USB cable. The SD card will be displayed as a separate drive in the computer.



Select PC Sync if you want to use the PC Tools software on your computer to transfer data.

The user has to restart the phone for these changes to take effect.

Calendar

The calendar enables you to set appointments, create appropriate notes, schedule reminders when required, set alerts and repeat specific settings. Tasks can be viewed on daily and weekly basis.

1. To access the Organizer and its associated functions, select **Menu > Tools > Calendar**. The calendar for the current month is displayed. Use the navigation keys to navigate across months.
2. Select **Option** to view the list of options available.
 - **View day:** You can view the list of events for the day.
 - **View week:** You can view the list of events for the week.
 - **New event:** You can enter a new event.
 - **Go to date:** You can go to a particular date and view the events for that date.
 - **Advanced:** You can find any event, delete all events or set whether the phone should notify the user if the calendar event expired during switched off state.

Edit Events

Select **Menu > Tools > Calendar > Option > View day**.
Select the event. Select **Option > Edit**. Make the changes.
Select **Save**.

Delete Events

Select **Menu > Tools > Calendar > Option > View day**.
Select the event. Select **Option > Delete**. Select **OK**.

Calculator

The calculator in this phone is designed to perform simple mathematical calculations.

1. Select **Menu > Tools > Calculator**.
2. To enter the numbers, press the numeric keys.
3. To use mathematical operators use the navigation keys.

Navigation Key	Operation
Up	+ (Addition)
Down	- (Subtraction)
Left	/ (Division)
Right	* (Multiplication)

4. After performing the calculations, press the **menu** key for the final result.
5. Select **Option** to display the following options.

Option	Function
Calculate	Performing calculations
Percentage	Percentage calculations
Modular	Modular division
MC	Clears number from memory
MR	Reads the number from memory
MS	Stores the entered number in memory
M+	Adds a number to the number in memory and stores the result in memory



This phone accepts numbers up to a maximum of 9 digits per entry.

55

Voice Recorder

Select **Menu > Tools > Voice recorder**.

1. To record an audio file, select **Option > New episode**.
2. To temporarily stop the recording, select **Pause**.
3. To continue with the recording, select **Resume**.
4. To end the recording, select **Stop**.
5. To select the storage location of the recorded file, select **Option > Select memory > Phone memory or Memory card**.

The recorded audio file is stored under My files. For more information refer “Managing Your Files” on page 62.

Audio Playback

The user can do instant playback of the recorded audio within the voice recorder. To listen to an recorded audio file, select **Menu > My files > Sounds**. Select the file.

AGPS

The Global Positioning System (GPS) is a Global Navigation Satellite System. It uses satellites that transmit precise microwave signals, which enable GPS receivers to determine their current location and time.



When an user accesses an application that requires GPS, then GPS is turned on automatically. After the application is closed, GPS is turned off automatically.

The GPS relies on satellite signal to calculate position. Under conditions of poor satellite reception (that is, under a tree, bad weather, and so on) standalone GPS receivers take long time (sometimes a few minutes) to provide location information to the users. The special feature Assisted GPS (AGPS) available in Sonim XP3.20 speeds up the phone’s process of calculating the position irrespective of the signal conditions. When AGPS is enabled, the phone automatically downloads the latest satellite related information (Ephemeris data) through GPRS. This information is used along with the satellite signals to calculate the position (Downloading of Ephemeris data may result in network charges).

Select **Menu > Tools > AGPS**. This allows the user to configure the usage of AGPS feature. This helps the user to control any network charges that is incurred due to downloading of Ephemeris. The following options are

displayed.

- **Never:** Ephemeris will not be downloaded and used.
- **Always:** Ephemeris data is downloaded once every day.
- **While Not Roaming:** Ephemeris data will not be downloaded if the phone is in roaming.

Stopwatch

Select **Menu > Tools > Stopwatch**.

1. To trigger the timer, select **Start**. The counter starts running.
2. To temporarily stop the counter, select **Pause**.
3. To resume running the counter, select **Go**.
4. To stop the counter, select **Stop**.

Unit Converter

You can convert one type of physical units to another type. Select **Menu > Tools > Unit converter**.

1. Select the type of physical unit. Use the Right or Left navigation keys to scroll. For example, Temperature.
2. Scroll down and select the Unit 1 for Temperature, for example, Fahrenheit.
3. Scroll down and enter the amount for Fahrenheit in Amount 1, for example, 80.
4. Scroll down and select the Unit 2 for Temperature, for example, Celsius.
5. The Temperature in Celsius is displayed in Amount 2.



Unit converter does not supports negative values.


Countdown Timer

This function is helpful when you need to be reminded of a specific event or you want to time a particular task.

1. Select **Menu > Tools > Countdown**.
2. Specify the time for the reminder in terms of hours and minutes. The maximum time you can set is 23 hours, 59 minutes and 59 seconds (23:59:59) and the minimum is one second (00:00:01).
3. When the countdown is completed, the alarm rings.

FM Radio

The FM radio is built-in and offers instant and easy access to FM radio channels in your phone. A wired headset must be attached to the phone, as the wire works as an antenna for the radio. You can then listen to the radio via the wired headset.



Select **Menu > Applications > FM Radio**. The radio starts playing. Select **Option** to display the following options.

- **Preset station:** You can view the radio stations that have already been saved. Select a radio station to play.
- **Search and save:** You can automatically save the radio channels.
- **Off:** You can switch off the radio.
- **Handsfree:** To play FM radio in the phone speaker, select **Option > Handsfree > On**.
- **Play in background:** You can play the radio in background. A strip in the screen indicates that radio is playing in background.

Camera

The Sonim XP3.20 has a 2MP (megapixel) camera for taking pictures. The pictures can then be saved in your phone.

- Select **Menu > Camera** OR press the **camera key**. The camera is switched on.
- Select the **menu key** OR press the **camera key** to shoot the picture.
- A message appears **Save photo?** Select **Yes** to save. The picture is saved in **Menu > My files > Pictures**.
- After clicking the picture, select **Option** to display the following options:
 - **Send:** You can send the picture to a phone number via Bluetooth.
 - **Delete:** You can delete the selected file.
 - **Capture:** You can capture a new picture.
 - **Set as contact picture:** You can set the captured picture as the picture against a contact. Only lower resolution pictures can be set as contact picture.



Only pictures with resolution 176x220 can be set as contact picture.

- **Set as wallpaper:** You can set the captured picture as the phone screen wallpaper.

Camera Options

To view the camera options, select **Menu > Camera > Option**. The following options are displayed:

- **Picture resolution:** Select the picture resolution from the following options: 1600*1200, 1280*1024, 1024*768, 640*480 or 176*220.
- **Picture quality:** Select the picture quality from the following options: Superfine, Fine or Normal.
- **View picture:** This option takes the user to the **Pictures** folder.
- **Camera Mode:** You can set the color effects and self-timer.
 - The color effects available are black and white, sepia and blue.
 - If you switch on self-timer, the picture will be shot only after a certain amount of time after pressing the menu key.
- **Flash:** Select **On** to turn on the flash or select **Off** to turn off the flash.
- **Advanced:** The advanced options available are.
 - **Storage location:** You can set the default location of pictures as **Phone memory** OR **Memory card**.
 - **Default name:** You can set the default name of the picture.
 - **Frequency:** You can set the frequency of power as **50 Hz** OR **60 Hz**.
 - **Full screen preview:** You can turn on the full screen preview during shooting.

Flashlight

You can use the camera flash as a flashlight. To turn ON/OFF the flash, **press and hold** key **5**. The flashlight can be turned ON/OFF from the following screens:

- Idle screen.
- Keypad locked screen.
- Main menu screen.
- Menu screens: Contacts, Messages, Create message, Settings, Call list and My files.
- Tools screen.
- Without SIM screen.



The flashlight button does not work if you are using camera or WAP.

Micro SD (Secure Digital) Card

In Sonim XP3.20 phone, you can insert a removable Micro SD Card to increase the storage capacity. This card is inserted into the slot inside the phone. You can perform the following functions on the SD card.


- Formatting of the SD card.
- Viewing memory details such as free space, used space and total space.
- Setting the images in the SD card as wallpaper.
- Setting the audio files in the SD card as ringtones.




The maximum capacity supported is upto 2 GB.

Inserting Micro SD Card into the Phone

1. Ensure the phone is switched off.
2. Lift the battery cover and remove the battery. For instructions refer **“Inserting the Battery” on page 14.**
3. Lift the silver clip over the designated slot located at the top left end of the battery slot.



4. Place the SD card in the designated slot and close the silver clip.



5. Replace the battery and the cover. Turn the battery cover screws clockwise to lock the battery cover.



When the Sonim XP3.20 phone is connected to a computer using USB, the Micro SD card is displayed as a separate drive in the computer.

Managing Your Files

Using the **My files** menu, you can store and manage audio files, picture files, .jar files, .jad files and .txt files. You can preview the files, view their details and delete files. The internal storage capacity is approximately 25 MB.

1. To view your files select **Menu > My files**.
2. Scroll to a category and select either **Pictures OR Sounds OR Others** and select **OK**.
3. For pictures, select the pictures that you would have saved. For sounds, select the audio files that you would have saved.
4. Scroll to file from the displayed list and select **Option** to display further options.

For a picture file, the following options are present.

Option	Function
View	You can view the picture in full screen mode.
Send	You can send the picture to any phone via Bluetooth.
Advanced	You can cut or copy the picture to another location. You can also rename the picture or view the details.
Use	You can use the picture as contact id or wallpaper.
Delete	You can delete the picture.
Slide show	You can view the pictures as a slide show.

Change view	You can view the pictures as a list or as a grid.
Sort	You can sort the pictures by name, date or size.
Select multiple	You can select all the pictures or select one by one.

For an audio file, the following options are present.

Option	Function
Play	You can play the audio file.
Send	You can send the audio file to any phone via Bluetooth.
Advanced	You can cut or copy the audio file to another location. You can also rename the audio file or view the details.
Use	You can use the audio file as contact id or ringtone.
Delete	You can delete the audio file.
Change view	You can view the audio files as a list or as a grid.
Sort	You can sort the audio files by name, date or size.
Select multiple	You can select all the audio files or select one by one.

Wired Headset

A wired headset is supplied along with the Sonim XP3.20 phone. A wired headset is a set of headphones attached to a microphone and connected to a phone using a wire connection. The connection is usually made via a headphone jack. A wired headset allows the user to both listen and speak. The wired headset also acts as an antenna for FM radio.

During Calls

1. To accept a call, press headset button to accept a call.
2. To end a call, press and hold the headset button.
3. To record the conversation, press the headset button during a call.
4. Long press the headset button to reject the call when it is ringing.

This wireless device, (the “Device”) contains software owned by Sonim Technologies, Inc. (“Sonim”) and its third party suppliers and licensors (collectively, the “Software”). As user of this Device, Sonim grants you a non-exclusive, non-transferable, non-assignable license to use the software solely in conjunction with the Device on which it is installed and/or delivered with. Nothing herein shall be construed as a sale of the Software to a user of this Device.

You shall not reproduce, modify, distribute, reverse engineer, decompile, otherwise alter or use any other means to discover the source code of the Software or any component of the Software. For avoidance of doubt, you are at all times entitled to transfer all rights and obligations to the Software to a third party, solely together with the Device with which you received the Software, provided always that such third party agrees in writing to be bound by these rules.

You are granted this license for a term of the useful life of this Device. You can terminate this license by transferring all your rights to the Device on which you have received the Software to a third party in writing. If you fail to comply with any of the terms and conditions set out in this license, it will terminate with immediate effect Sonim and its third party suppliers and licensors are the sole and exclusive owner of and retain all rights, title and interest in and to the Software. Sonim, and, to the extent that the Software contains material or code of a third party, such third party, shall be entitled third party beneficiaries of these terms. The validity, construction and performance of this license shall be governed by the laws of Delaware, United States.

Unconditional 3 Year Guarantee

Sonim provides this Unconditional three year Guarantee for your mobile phone (hereinafter referred to as Product”).

Should your Product need guaranty service, please return it to the retailer from whom it was purchased, or contact

- Online Support and country specific toll free numbers: www.sonimtech.com/support
- Email: support@sonimtech.com

Our Guarantee

Subject to the conditions of this Unlimited 3 year Guarantee Sonim warrants this product to be free from major defects in design, material and workmanship at the time of its original purchase by a consumer, and for a subsequent period of Three (3) years.

What We Will Do

If during the guarantee period, this product fails to operate under normal use and service, due to defects in design, material or workmanship, Sonim’s authorised distributors or service partners, in the country/region where you purchased the product, will replace with the same or better model in the same or better condition. Sonim and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads or other information may be lost when your Sonim Product is repaired or replaced. Sonim does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss.

You should always make backup copies of all the information stored on your Sonim Product such as downloads, calendar and contacts before handing in your Sonim Product for repair or replacement.

Phone Care

The Sonim XP3.20 is designated class IP67 for dust and water protection, according to the IEC Ingress Protection (IP) Standard 60529. This means that the phone is dust protected and can be submerged into 1.0m deep water for up to 30 minutes. Immersion in deeper water can damage it and must be avoided. The phone is not water-proof or water resistant during charging, use of a plug-in headset, or any other use when the system connector cover on the bottom of the phone is not tightly enclosed.

The Sonim XP3.20 is solid and built for heavy duty use. Its design protects against disassembly or mechanical damage when subjected to forces equal to free fall from the high of an average adult. Subjecting the phone to stronger impact and forces can damage it and must be avoided.

Conditions

1. The warranty is valid only if the original proof of purchase issued to the original purchaser by a Sonim authorised dealer, specifying the date of purchase and serial number for this Product, is presented with the Product to be repaired or replaced. Sonim reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.
2. If Sonim repairs or replaces the Product, the repaired or replaced Product shall be warranted for the remaining time of the original warranty period or for

ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sonim.

3. This warranty does not cover any failure of the Product due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with the Sonim instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to accident, software or hardware modification or adjustment, acts of God or damage resulting from liquid interacting with the product beyond what is described as acceptable in the user guide for the product. A rechargeable battery can be charged and discharged hundreds of times. However, it will eventually wear out - this is not a defect. When the talk-time or standby time is noticeably shorter, it is time to replace your battery. Sonim recommends that you use only batteries and chargers approved by Sonim. Minor variations in display brightness and colour may occur between phones. There may be tiny bright or dark dots on the display. These are called defective pixels and occur when individual dots have malfunctioned and can not be adjusted. Several defective pixels are deemed acceptable.
4. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sonim authorised person. Tampering with any of the seals on the Product will void the warranty.

5. The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sonim branded original accessories intended for use with the Product.
6. THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONIM OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS; TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW. DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONIM OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS; TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

WARNING: Changes or modifications made to this equipment not expressly approved by Sonim Technologies, Inc. for compliance could void the user's authority to operate the equipment.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Declaration of Conformity

Sonim Technologies Inc, declares that the mobile phone Sonim XP3.20™ is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.



Declaration of Conformity

We, Sonim Technologies, Inc. 1875 S. Grant Street, Suite 620, San Mateo CA 94402, US declare under our own responsibility that our products

Type: P22C001BB, P23C001BB

Model: Sonim XP3.20-E Quest pro, Sonim XP3.20-A Quest pro

to which this declaration refers, alone and in combination with our accessories conform with the relevant standards:

Safety: EN 60950-1:2006

SAR: EN50360:2001/EN50361:2001

RF: EN EN301-511 V9.0.2 EN 300 328 V1.7.1

EMC: EN301489-1 V1.8.1 (2008-04), EN301 489-7 V1.3.1 (2005-11),

EN301 489-17 V1.3.2 (2008-04)

3GPP: TS 51.010-1

We hereby declare that all essential radio test suites have been carried out and that the above named products are in conformity to the essential requirements of Radio and Telecommunication Terminal Equipment Directive 1999/5/EC.

The conformity assessment procedure according to the regulations in R&TTE Directive 1999/5/EC has been followed with the involvement of the following Notified Body:

BABT, Balfour House, Churchfield Rd, Walton-on-Thames, Surrey, KT1 2TD, UK.
Notified Body Number 0168.

The technical documentation relevant to the above products will be held at:

Sonim Technologies, Inc.
1875 S. Grant Street, Suite 620, San Mateo, California 94402, USA

San Mateo, November 4, 2009

A handwritten signature in black ink, appearing to read "Jans K. G.", is written over a faint circular stamp.

The original copy of this Declaration of Conformity is signed.

A**Access Point Name (APN)** 50, 51**Alarm clock** 52**Audio**

Playback 56

Recorder 55

Auto-power ON/OFF 31**B****Bar calls**

Cancel 37

Status 37

Battery

Bars 15

Charge 15, 20

Usage 14

Bluetooth

Activate 52

Deactivate 52

Headset 53

Pair devices 53

Receive data 54

Send data 53

Settings 52

Bookmarks 49**C****Calculator** 55**Calendar** 54**Call accept/Send key** 19**Call list** 34**Calls on hold/waiting** 36**Camera** 58, 59

Flash 59

Options 59

Car mode 29**Connectivity settings** 32**Contacts** 40

Add 40

Delete 42

Group 40

Move or copy 42

Send 41

Send message 40

Count-down timer 57**Create messages** 44**D****Display settings** 32**F****Filter calls** 38**Firewall**

Black list 31

White list 31

Fixed number dialing 37**Flashlight** 60**Flight mode** 29**FM radio** 58**Forward calls** 36**G****General settings** 29**GPRS** 35, 38**GSM**

Dial 34

Send phone number 34

H**Handsfree dial** 34**Hardcoded shortcuts** 46**Hardcoded Shortcuts** 48**Home mode** 29**Homepage** 49**I****International clock**

Daylight saving time 30

Local settings 30

International number dialling 34**J****Java**

Installing Java Application From

SD Card 51

Installing Java Application From

WAP 51

Installing Pre-bundled Java Applications 51

K

Keypad

Accept/Send 22
End call 22
Function keys 17
LSK/RSK 22
Navigation keys 19, 23
Power On/Off 22
XP3.2 19

L

Left Selection Key 19

M

Managing your files 62

Meeting mode 29

Memory 43

Memory status 31

Menu

Call list 25, 34
Key 20, 22
Main 25
Messages 25, 43
My files 25, 62
Phone book 25, 40
Quick settings 25
Settings 25, 29
SIM toolkit 25, 47
Tools 25, 52

WAP 25, 49

Messages

Delete 45
Dial sender 45
Forward 45
Inbox 45, 46
Predefined SMS 45
Save sender's number 45
Sent 45
SMS memory 46
Unsent 45
Write 44

Message settings 43

Memory 43
Reply path 43
Service number 43
Signature 43
Status report 43
Validity period 43

Micro SD card 61

Insert 61

My files 62

O

Opera Mini 50, 51

Access Point Name (APN) 50, 51
Network account 50

Organizer

Delete entries 53
Edit entries 53

Outdoor mode 29

P

Pair devices 53

Personal mode 29

Phone languages 30

Predefined message 46

Predefined SMS 45

Profiles 29

Car 29
Flight 29
Home 29
Meeting 29
Outdoor 29
Personal 29
Silent 29

R

Recording a call 39

S

Security settings 31

Silent mode 29

SMS memory 46

Sound settings 32

Speed dial 35

Standby mode duration 20

Stopwatch 56

T**Text input mode**

- Conventional **43**
- Predictive **43**

Themes 32**Tools**

- Alarm clock **52**
- Audio playback **55**
- Audio recorder **55**
- Bluetooth **52**
- Calculator **55**
- Calendar **54**
- Camera **58**
- Count-down timer **57**
- Flashlight **60**
- FM radio **58**
- GPS **56**
- opera mini **50, 51**
- Stopwatch **56**
- Unit converter **56**
- USB function **54**

Bookmarks **49**

Cache **49**

Homepage **49**

Push inbox **49**

Settings **49**

Wired Headset 63**Write Messages 44****U****Unit converter 56****USB function 54****V****Voicemail 19****W****WAP 49**

- Address **49**