












## Gazebo/Pergola

Trädgårdspaviljong, pergola  
Hagepaviljong/Pergola  
Puutarhapaviljonki/ pergola  
Gartenpavillon/Pergola

Art.no 31-4513 Model DU025



 A × 6	 B × 6
 C × 6	 C1 × 6
 D × 1	 E × 1
 F × 1	 G × 12
 H × 24 M6 × 30	 I × 2

Ver: 20161122

**GREAT BRITAIN** • customer service tel 020 8247 9300 e-mail customerservice@clasohlson.co.uk  
internet www.clasohlson.co.uk postal 10 – 13 Market Place, Kingston Upon Thames, Surrey, KT1 1JZ

**SVERIGE** • kundtjänst tel. 0247/445 00 fax 0247/445 09 e-post kundservice@clasohlson.se  
internet www.clasohlson.se brev Clas Ohlson AB, 793 85 INSJÖN

**NORGE** • kundesenter tel. 23 21 40 00 fax 23 21 40 80 e-post kundesenter@clasohlson.no  
internett www.clasohlson.no post Clas Ohlson AS, Postboks 485 Sentrum, 0105 OSLO

# clas ohlson

