

EXIBEL®

Car Handsfree Bluetooth Autohandsfree Bluetooth

Art.no.
36-3553

Model
Alpha BT V.1.2

English	3
Suomi	21

Car Handsfree Bluetooth

Art.no 36-3553, model Alpha BT V.1.2

Please read the entire instruction manual before using the product and save it for future reference. We reserve the right for any errors in text or images and any necessary changes made to technical data. If you have any questions concerning technical problems please contact our Customer Services (see address on reverse).







Safety

- Always check the local legislation regarding use of mobile phones and handsfree equipment while driving.
- Do not expose the product to extreme temperatures or direct sunlight.
- Never expose the product to moisture, liquid or humidity.
- Use only rechargeable batteries.
- Never mix rechargeable and alkaline batteries, also never mix old and new batteries.
- Use only the included or recommended charger.
- Never take apart the product or its accessories. The product should only be repaired by qualified service personnel.

Product Description

- Caller ID in clear foldable display.
- DSP technology for effective noise and echo cancellation.
- Battery operated (3 x LR03/AAA) makes it possible to mount it cordless.
- Easy to install, attaches directly on the car's sun visor or can be used in meetings as a conference phone where everyone can talk and listen.
- Built-in microphone and speaker.
- Supports for voice dialling (if the phone supports that).
- Phone book with memory for up to 600 entries.
- Comes with car charger for 12/24 V DC.

Buttons and Functions


	<ul style="list-style-type: none"> • Answering a call • Confirm settings in menus • Voice dialling (2 sec.)
	<ul style="list-style-type: none"> • Finish a call • Go back in menus • Callback feature (2 sec.)
	<ul style="list-style-type: none"> • Move down in menus • Choosing phone (A/B)
	<ul style="list-style-type: none"> • Activate menu • Move up in menus
	<ul style="list-style-type: none"> • Decreases the volume
	<ul style="list-style-type: none"> • Increases the volume

Getting Started

1. Open the battery compartment by sliding it straight back and insert 3 x HR03/AAA-batteries. Make sure to install the batteries according to the markings in the battery compartment.

Important! Charge the batteries for a minimum of 6 hours before first use.


2. Replace the battery cover.
3. Mount the sun visor on the tracks according to the figure. Press the attachment all the way until a click sound is heard and the attachment is locked in place.
4. Attach the unit on the sun visor according to the figure. Tilt the display to the desired angle.





Loosening the sun visor attachment

If you want to loosen the sun visor, press the attachments catch with a screwdriver according to the figure and simultaneously press the attachment in the arrow's direction.

Charging the batteries

When the unit gives out several tones and the symbol  is shown on the display it is time to charge the unit's batteries.

1. Connect the included car charger in the car's cigarette outlet and then to the connection on the side of the device. The symbol  on the display indicates that the charging is in progress.
2. When the batteries are fully charged  is shown on the display, the charger can now be disconnected.

Using the headphone outlet

To the headphone outlet (3.5 mm) on the left side of the unit a pair of headphones can be connected. The internal speaker quietsens when headphones are connected.

Preparations

Turning the radio on/off

Turn on

Turn the display out, the unit gives out a short sound signal and the display is lit.

Turn off

Turn back the display to its original position, the device shuts off itself after a few seconds.

Creating a Bluetooth connection


Before the mobile phone and the handsfree unit are used together for the first time a connection (pairing) has to be created. When this is done the connection is saved in the respective unit.

- Two mobile phones can be connected simultaneously.
 - The handsfree unit has memory capacity for up to 8 mobile phones.
1. Place the mobile phone and the handsfree unit no more than a metre apart.
 2. Activate the Bluetooth function on the mobile phone (if the mobile phone has pre-configured “Profiles” it is recommended that the handsfree profile is used instead of the headset profile).
 3. Turn on the handsfree. The display indicates “A” (for the first phone) and P (connection mode). The connection mode is activated automatically for 4 minutes.
 4. Choose searching for new Bluetooth unit in the mobile phone’s menu (see the mobile phone’s instruction manual).
 - The mobile phone searches for available units within approx. 10 metres and displays them in a list.
 - Choose to connect to unit **Exibel** and enter the password **1234** when the password is asked for.
 5. The connection is now ready and the units are ready to be used together. The phone’s Bluetooth name is shown on the unit’s display with a symbol representing a car.

N.B.


- On some phones the connection must be activated and approved after the connection procedure has been made. Choose to manually activate the connection to the unit **Exibel** (see the mobile phone's instruction manual).
- If the connection has failed, repeat the connection procedure again.
- If you do not want to create a new connection when the handsfree unit is turned on, wait a moment and let the unit automatically search and connect to an already connected mobile phone.

Connecting another phone

- Press  once directly after step 5.
- The display indicates "B" (for the second phone) and P (connection mode).
- Repeat steps 4 and 5.


Choose connected phone

If you have connected several mobile phones you can choose for which phone the current features should function for.

- In the wait mode, press  to choose connected mobile phone. The display shows which phone has been selected, "A" or "B" and the name of the mobile phone.







Operation

Making a call

1. Enter the phone number as usual on the mobile phone and press call.
2. The call is connected to the handsfree unit.
3. Press Hang up on the mobile phone or press  on the unit when you want to finish the call.

Making a call from the phone book

To make a call from the phone book via the handsfree unit you must first have transferred your contacts from the mobile phone. See section Phonebook.

1. Choose **Phonebook** in the menu and confirm with .
2. Choose **Ph.B.** review and confirm with .
3. Press  to in alphabetical order choose the first letter of the name you are searching for (the first contact for each letter in the alphabet is shown).
4. Then press  until you have found the desired contact. If there are several numbers on the same name, press until the desired number for the name is shown.
5. Press  to call the chosen contact. The call is connected to the phone and the sound is transferred to the handsfree unit.
6. Press  when you want to finish the call.

Answering a call

When an incoming call is received, the unit sounds, press  to answer the call.



Refusing an incoming call

Press  to refuse an incoming call.


Answer a call on the other phone

If you have two mobile phones connected you can during a call on one phone, answer an incoming call on the other phone.

Example:

1. Telephone A has a current call on the handsfree unit.
2. When an incoming call is received by telephone B the unit sounds to notify the user that there is a new call.
3. Press  to answer the call. The sound from telephone A is silenced and the call in telephone B can begin.
4. Press  to finish the call. When the call in telephone B is finished, the call from telephone A is resumed.


Turning off the microphone (mute)

- Press  to temporarily turn off the microphone. You can now have a private conversation without the person on the phone being able to hear you (tones indicate that the mute function is activated).
- Press again to turn on the microphone.

Voice dialling


Call a contact by saying his/her name.

The mobile phone must support voice dialling and voice commands must be stored for the contacts you wish to call using voice dialling. Follow the mobile phone's instruction manual.

1. Make sure voice dialling is activated on the mobile phone.
2. Press and hold  for approx. 2 seconds until the display shows Voice Dial.
3. Say the name after the tone. The phone calls the contact.

Transferring calls to the mobile phone

If you want to have a private conversation without the handsfree feature.






- During current call, press  to transfer the call to the mobile phone. The handsfree unit's speaker and microphone are shut off. Press the button again to return to the handsfree.

Automatic redial

Automatic redialling of the latest dialled number.





- Press and hold the automatic redialling button  for approx. 2 seconds to call the latest dialled number.

Using the menus

1. Open the menu by pressing  once.
2. Then use  and  to go to the desired sub-menu.
3. Confirm your choice and settings by pressing .
4. Press  to exit the menus.

Languages

If you want to change the language in which the menus are displayed. Available languages: English, Spanish, French, German, Italian, and Portuguese.



1. Choose **Languages** in the menu and confirm with .
2. Choose desired language with  or . Confirm your choice with .

Phonebook

Allows you to via Bluetooth transfer the mobile phone's contacts to the handsfree unit. Up to 600 entries can be stored in the phone book.

N.B. The mobile phone must be able to support the transfer of a phone book via Bluetooth. See your mobile phone's instruction book.


Transferring the entire phone book (Ph.B. reading)

1. Make sure that the mobile phone is connected to the handsfree unit (the display shows the phone's name and/or the car icon on the bottom part of the display)
2. Choose **Phonebook** in the menu and confirm with .
3. Choose **Ph.B. reading** and confirm with .
4. The transfer of the phonebook starts in a moment. The unit's display shows the names and numbers that have been transferred.

N.B. Do not touch any of the buttons and do not move the phone away from the unit whilst the transfer is in progress.

5. When the transfer is completed, press  to finish.




N.B.

If the mobile phone does not support transfer via Bluetooth the message "Phonebook push" in the unit's display. Press  to finish.




Transferring specific contacts

1. Make sure that the mobile phone is connected to the handsfree unit.
2. Choose in the mobile phone to send one or several contacts via Bluetooth to the handsfree unit. Follow the mobile phone's instruction manual.
3. The actual contact is show on the unit's display when the transfer occurs.

Displaying a number in the phonebook (Ph.B. review)

1. Choose **Ph.B. review** and confirm with .
2. Press  to in alphabetical order choose the first letter of the name you are searching for.
3. Then press  until you have found desired contact. If there are several numbers under the same name, press until the desired number for the name is shown.

Erasing the entire phone book (Ph.B. delete)

1. Choose Ph.B. delete and confirm with .
2. The display shows "Delete the phone book".
 - Press  to confirm that you want to erase the phonebook. **N.B.** This action cannot be reversed!
 - Press  to finish without erasing.

Received Calls

Choose **Received Calls** to display received calls.

Call up a received number:

- Mark the number with  or . Then press  to call up the number.

Missed Calls

Choose **Missing Calls** to display missed calls.

Calling up a missed number:

- Mark the number with  or . Then press  to call up the number.



Dialled Out Calls

Choose **Dial Out Calls** to display previous called numbers.

Calling up a previously called number:




- Mark the number with  or . Then press  to call up the number.

Hot Key

Choose a number in the phonebook that you want to call by pressing  and  simultaneously.

The feature can be used for e.g. an emergency number, voice mail etc.

Storing a hot key:

1. Find the number you want to store as a hot key.
2. Press  and  simultaneously to store the number.
3. Then press  to finish and go back to standby mode.

LCD reverse

Depending on how the handsfree unit is mounted or used the display can be turned upside down for best visibility.

- Choose **LCD reverse** and confirm with . The display is turned upside down.

Media Player



The handsfree unit can play the music that is stored on the phone. The phone must be A2DP compatible for streaming of media via Bluetooth.

Starting playback

1. Make sure that the mobile phone is connected to the handsfree unit.
2. Start the playback of music in the mobile phone. The sound is played in the handsfree unit and a headphone icon is shown on the display.

Changing track, pausing or stopping playback

You can control the playback directly from the handsfree unit.

1. Choose **Media player** and confirm with .
2. Mark the desired feature to control the playback:
 - ▶ – Playback
 - – Stop
 - II – Pause
 - I◀◀ – Previous track
 - ▶▶I – Next track
3. Confirm your choice with .

Tip: You can also control the playback as usual from your mobile phone.

Adjusting the volume

Adjust the volume with the volume control. The display shows set volume.



– Lowers the volume



– Increases the volume

N.B.

- Too high volume may cause echo during the call. Adjust the volume to desired level.
- Do not press the buttons simultaneously since you then call the hot key number.

Care and maintenance

Use a soft damp cloth to clean the product. Never use solvents or strong detergents.

Disposal

Follow local ordinances when disposing of this product. If you are unsure how to dispose of the product, please contact your municipality.

Specifications

Bluetooth interface	Version 1.2 compatible (class II). Adaptive Frequency Jump Lesser interference risk. Data rate: 723 kbps. Reduction against radio interferences from e.g. WLAN.
Profile	A2DP/AV stereo.
Frequency	2.45 GHz.
Range	Approx. 10 metres (class 2)
Phonebook	Up to 600 entries.
Phone support	Memory for 8 telephones.
Display	Numerical background lit 4 lines display with 18 symbols per line.
DSP	Full duplex. Noise and echo reduction.
Talk time	Up to 8 hours.
Battery size	3 x HR03/AAA rechargeable batteries (included).
External power source	12-24 V DC.
Speaker power output	2 W max.
Ambient temperature	- 10 °C to 40 °C.
Size (WxHxD)	120 x 23 x 93 mm.

Autohandsfree Bluetooth

Tuotenro. 36-3553, malli Alpha BT V.1.2

Lue käyttöohjeet ennen tuotteen käyttöönottoa. Säilytä käyttöohjeet tulevaa tarvetta varten. Pidätämme oikeuden teknisten tietojen muutoksiin. Emme vastaa mahdollisista teksti- tai kuvavirheistä. Jos laitteeseen tulee teknisiä ongelmia, ota yhteys myymälään tai asiakaspalveluun (yhteystiedot käyttöohjeen lopussa).







Turvallisuus

- Ota selvää matkapuhelimen ja handsfree-laitteen käytöstä autolla ajettaessa paikallisesta lainsäädännöstä.
- Älä altista laitetta korkeille lämpötiloille tai suoralle auringonvalolle.
- Älä altista laitetta kosteudelle, nesteille tai korkealle ilmankosteudelle.
- Käytä ainoastaan ladattavia akkuja.
- Älä käytä ladattavia paristoja ja alkaliparistoja, äläkä vanhoja ja uusia paristoja yhdessä.
- Käytä vain pakkauksen laturia tai käyttöohjeessa suositeltuja latureita.
- Älä koskaan avaa laitetta tai sen tarvikkeita, Laitteen saa korjata vain valtuutettu huoltoliike.

Tuotekuvaus

- Selkeä ja taitettava numeronäyttö.
- DSP alentaa kohinaa ja kaikua.
- Akku (3 x LR03/AAA). Mahdollista asentaa ilman johtoja.
- Yksinkertainen asennus. Kiinnitetään suoraan auton aurinkosuojaan tai käytetään kokouspuhelimena, jolloin kaikki voivat kuunnella ja puhua.
- Sisäinen kaiutin ja mikrofoni.
- Tukee äänikomentoa (jos puhelinkin tukee).
- Puhelinmuistio 600 kontaktille.
- Mukana autolaturi 12/24 V DC.

Painikkeet ja toiminnot


	<ul style="list-style-type: none"> • Puheluun vastaaminen • Vahvista valikoiden asetukset • Äänikomento (2 sekuntia)
	<ul style="list-style-type: none"> • Puhelun lopetus • Palaa takaisin valikoissa • Viimeksi valitun numeron uudelleenvalinta (2 sekuntia)
	<ul style="list-style-type: none"> • Siirry alaspäin valikoissa • Puhelimen valinta (A/B)
	<ul style="list-style-type: none"> • Valikon aktivointi • Siirry ylöspäin valikoissa
	<ul style="list-style-type: none"> • Vähennä äänenvoimakkuutta
	<ul style="list-style-type: none"> • Lisää äänenvoimakkuutta

Käytön aloittaminen

1. Avaa akkulokeron luukku työntämällä sitä suoraan ulospäin ja aseta lokeroon 3 HR03/AAA-akkuja. Varmista, että akut tulevat oikein päin.

Tärkeää! Lataa paristoja vähintään 6 tuntia ennen ensimmäistä käyttökertaa.

2. Aseta akkulokeron kansi takaisin käänteisessä järjestyksessä.
3. Asenna aurinkosuojakiinnike laitteen uriin kuvan mukaisesti. Työnnä kiinnike kokonaan kiinni, kunnes kuulet napsahduksen ja kiinnike lukittuu paikoilleen.
4. Kiinnitä laite aurinkosuojaan kuvan osoittamalla tavalla. Käännä näyttö haluttuun kulmaan.





Irrota aurinkosuojakiinnike

Kun haluat irrottaa aurinkosuojakiinnikkeen, paina kiinnikkeen lukitushaka alas ruuvitaltan avulla kuvan mukaisesti ja vedä samalla kiinnikettä nuolen suuntaan.

Akkujen lataaminen

Kun laitteesta kuluu merkkiäänä ja kuvake  näkyy näytöllä, on aika ladata akut.

1. Liitä pakkauksen autolaturi auton savukkeensytytinliitäntään ja laitteen sivulla olevaan latausliitäntään. Näytön kuvake  kertoo latauksen olevan meneillään.
2. Kun akut on ladattu täyteen, ilmestyy näytölle kuvake  ja voit irrottaa laturin.

Kuulokeliitännän käyttäminen

Voit liittää stereokuulokkeet laitteen vasemmalla sivulla olevaan kuulokeliitäntään (3,5 mm). Kun kuulokkeet liitetään, ei sisäisestä kaiuttimesta kuulu ääntä.

Esivalmistelut

Käynnistys ja sammutus

Käynnistys

Käännä näyttöosaa ulospäin, laiteesta kuuluu lyhyt merkkiäänä ja näyttöön syttyy valo.

Sammutaminen

Käännä näyttöosa takaisin alkuperäiseen asentoon. Laite sammuu itsestään muutaman sekunnin kuluttua.

Bluetooth-yhteyden muodostaminen


Ennen kuin matkapuhelinta ja handsfree-laitetta voidaan käyttää yhdessä ensimmäistä kertaa, on niiden välille luotava yhteys (pairing). Kun paritus on tehty, liittymä tallentuu kumpaankin laitteeseen.

- Kaksi matkapuhelinta voi olla liitettynä samaan aikaan.
 - Handsfree-laitteen muistiin mahtuu jopa 8 matkapuhelinta.
1. Aseta matkapuhelin ja handsfree-yksikkö metrin etäisyydelle toisistaan.
 2. Aktivoi matkapuhelimen bluetooth-toiminto (jos matkapuhelimessa on valmiit profiilit, suosittelimme handsfree-profiilia kuulokeprofiiliin sijasta).
 3. Laita handsfree-yksikkö päälle. Näytöllä lukee "A" (ensimmäinen puhelin) ja "P" (liitántätilä). Liitántätilä aktivoituu automaattisesti 4 minuutin ajaksi.
 4. Etsi matkapuhelimella uusi bluetooth-yksikkö (katso matkapuhelimen käyttöohjeesta).
 - Matkapuhelin etsii noin 10 metrin sisällä olevia bluetooth-yksiköitä ja näyttää löydettyistä yksiköistä listan.
 - Valitse listalta yksikkö **Exibel** ja kirjoita salasanaaksi **1234**, kun salasanaa kysytään.
 5. Yhteys on nyt valmis ja yksiköitä voi käyttää yhdessä. Puhelimen Bluetooth-nimi näkyy yksikön näytöllä yhdessä auton muotoisen kuvakkeen kanssa.

Huom.!


- Joissakin puhelimissa pitää liitää vielä erikseen aktivoida ja hyväksyä liittämisen jälkeen. Katso matkapuhelimen käyttöohjeesta, kuinka liitää **Exibel**-yksikköön aktivoidaan manuaalisesti.
- Jos yhteyden muodostaminen on epäonnistunut, tee liittäminen uudestaan alusta.
- Jos et halua muodostaa uutta yhteyttä, kun handsfree-laite käynnistetään, odota hetki ja anna laitteen etsiä automaattisesti jo liitetty matkapuhelin ja muodostaa yhteys siihen.

Liitä toinen puhelin

- Paina kerran painiketta  heti 5. kohdan jälkeen.
- Näytöllä lukee ”B” (toinen puhelin) ja ”P” (liitääntätila).
- Toista kohdat 4 ja 5.


Valitse liitetty puhelin

Jos olet liittänyt useampia matkapuhelimia, voit valita toiminnan kohteeksi yhden näistä puhelimista.

- Valitse matkapuhelin painamalla odotustilassa  -painiketta. Näytöllä lukee valitun matkapuhelimen nimi sekä ”A” tai ”B”.







Käyttö

Puhelun soittaminen

1. Näppäile puhelinnumero tavalliseen tapaan matkapuhelimeen ja paina puhelimen soitto-painiketta.
2. Puhelu yhdistyy handsfree-laitteeseen.
3. Päätä puhelu painamalla matkapuhelimen lopetus-painiketta tai bluetooth-yksikön  -painiketta.

Numeron valinta puhelinmuistiosta

Jos haluat soittaa puhelinmuistiostasi olevaan numeroon handsfree-laitteen kautta, täytyy sinun ensin siirtää puhelinnumerot matkapuhelimen puhelinmuistiosta. Katso kohta ”Puhelinmuistio”.

1. Valitse valikosta **Phonebook** ja vahvista painamalla .
2. Valitse **Ph.B. review** ja vahvista painamalla .
3. Voit etsiä haluamaasi puhelinnumeroa aakkosjärjestyksessä nimen ensimmäisen kirjaimen mukaan painamalla  (näet ensimmäisen nimen jokaisen kirjaimen kohdalta).
4. Paina sitten , kunnes löydät haluamasi nimen ja numeron. Jos samalle nimelle löytyy useampia numeroita, paina kunnes löydät haluamasi numeron.
5. Soita valittuun numeroon painamalla . Puhelu yhdistyy puhelimen kautta ja ääni siirtyy handsfree-laitteeseen.
6. Lopeta puhelu painamalla .

Puheluun vastaaminen

Laitte hälyttää puhelun tullessa. Vastaa puheluun painamalla  .



Tulevan puhelun hylkääminen

Hylkää tuleva puhelu painamalla  .


Toisen puhelimen puheluun vastaaminen

Jos olet liittänyt handsfreehen kaksi puhelinta, voit toiseen puhelimeen puhuessasi vastata toiseen puhelimeen saapuvaan puheluun.

Esimerkki:

1. Puhut parhaillaan puhelimeen A handsfree-laitteen kautta.
2. Puhelun tullessa puhelimeen B, ilmoittaa laitteen merkkiääni uudesta puhelusta.
3. Vastaa puheluun painamalla  . Ääni A-puhelimesta mykistyy ja voit aloittaa ”B”-puhelimen puhelun.
4. Lopeta puhelu painamalla  . Kun B-puhelimen puhelu on päättynyt, A-puhelimen puhelu jatkuu.


Mikrofonin mykistäminen

- Mykistä mikrofoni väliaikaisesti painamalla  . Näin voit keskustella rauhassa ilman, että vastapuoli kuulee sinua (merkkiäänet kertovat, että mykistystoiminto on aktivoitu).
- Uusi painallus käynnistää mikrofonin uudelleen.

Puheohjattu numerovalinta

Soita henkilölle sanomalla vain hänen nimensä.

Matkapuhelimesi on tuettava ääniohjausta ja ne kontaktit, joille haluat ääniohjauksella soittaa, on merkittävä muistiin. Katso matkapuhelimen käyttöohjeesta.

1. Varmista, että puheohjattu numerovalinta on aktivoitu matkapuhelimessa.
2. Paina  -painiketta noin kahden sekunnin ajan, kunnes näytöllä lukee ”Voice Dial”.
3. Sano nimi merkkiäänän jälkeen. Puhelin soittaa kyseiselle kontaktille.

Puhelun siirtäminen matkapuhelimeen

Jos haluat puhua ilman handsfree-toimintoa.






- Siirrä puhelu matkapuhelimeen painamalla  puhelun aikana. Handsfree-laitteen kaiutin ja mikrofoni sammuvat. Paina painiketta uudelleen palataksesi handsfree-toimintoon.

Uudelleenvalinta

Viimeksi valitun numeron uudelleenvalinta





- Soita viimeksi valittuun numeroon painamalla uudelleenvalintapainiketta  noin kahden sekunnin ajan.

Valikoiden käyttö

1. Avaa valikko painamalla kerran .
2. Siirry haluamaasi alavalikkoon  - ja  -painikkeilla.
3. Vahvista valinnat ja tekemäsi asetukset painamalla .
4. Palaa taaksepäin ja poistu valikoista painamalla .

Kieli (Languages)

Jos haluat vaihtaa valikoiden kieltä. Valikon kielinä on: englanti, espanja, ranska, saksa, italia ja portugali.



1. Valitse valikosta **Languages** ja vahvista painamalla .
2. Valitse haluamasi kieli painikkeella  tai . Vahvista valintasi painamalla .

Puhelinmuistio (Phonebook)


Voit Bluetoothin välityksellä siirtää matkapuhelimen muistissa olevia numeroita handsfreelaitteeseen. Voit tallentaa puhelinmuistioon jopa 600 numeroa.

Huom.! Matkapuhelimen on tuettava puhelinmuistion siirtämistä Bluetoothilla. Katso lisää matkapuhelimesi käyttöohjeesta.


Koko puhelinmuistion siirtäminen (Ph.B. reading)

1. Varmista, että matkapuhelin on liitetty handsfree-laitteeseen (näytöllä lukee puhelimen nimi ja/tai autokuvake näkyvän näytön alaosassa).
2. Valitse valikosta **Phonebook** ja vahvasta painamalla .
3. Valitse **Ph.B. reading** ja vahvasta painamalla .
4. Puhelinmuistion siirtäminen alkaa hetken kuluttua. Handsfree-laitteen näytöllä lukee siirrettävät nimet ja puhelinnumerot.

Huom.! Älä koske painikkeisiin äläkä siirrä puhelinta kauemmaksi laitteesta puhelinmuistion siirron aikana.

5. Kun siirto on valmis, lopeta painamalla .




Huom.!

Jos matkapuhelin ei tue Bluetooth-tiedonsiirtoa, lukee handsfree-laitteen näytöllä ”Phonebook push”. Lopeta painamalla .




Yksittäisten puhelinnumeroiden siirto

1. Varmista, että matkapuhelin on yhteydessä handsfree-laitteeseen.
2. Valitse matkapuhelimesta, haluatko lähettää handsfree-laitteeseen yhden vai useampia numeroita Bluetoothin kautta. Katso matkapuhelimen käyttöohjeesta.
3. Siirrettävä puhelinnumero näkyy laitteen näytöllä siirron ajan.

Numeron etsiminen puhelinmuistiosta (Ph.B. review)

1. Valitse **Ph.B. review** ja vahvista painamalla .
2. Valitse etsimäsi puhelinnumeron nimen ensimmäinen kirjain aakkosjärjestyksessä painamalla .
3. Paina sitten , kunnes löydät haluamasi nimen ja numeron. Jos samalle nimelle löytyy useampia numeroita, paina kunnes löydät haluamasi numeron.

Koko puhelinmuistion poistaminen (Ph.B. delete)

1. Valitse **Ph.B. delete** ja vahvista painamalla .
2. Näytöllä lukee ”Delete the phone book?”.
 - Vahvista, että haluat poistaa puhelinmuistion painamalla .
- **Huom.!** Toimenpidettä ei voida perua!
- Lopeta poistamatta puhelinmuistiota painamalla .

Vastaanotetut puhelut (Received Calls)

Näet vastaanotetut puhelut valitsemalla **Received Calls**.

Soittaminen vastaanotettuun numeroon:

- Valitse numero painikkeella  tai . Soita valitsemaasi numeroon painamalla .

Vastaamattomat puhelut (Missing Calls)

Näet vastaamattomat puhelut valitsemalla **Missing Calls**.

Soittaminen vastaamattomaan numeroon:

- Valitse numero painikkeella  tai . Soita valitsemaasi numeroon painamalla .

Soitetut puhelut (Dial Out Calls)


Näet soitetut puhelut valitsemalla **Dial Out Calls**.

Soittaminen aikaisemmin valittuun numeroon:

- Valitse numero painikkeella  tai . Soita valitsemaasi numeroon painamalla .

Lyhytnumero (Hot key)




Valitse puhelinmuistiosta numero, johon voit soittaa painamalla samanaikaisesti painikkeita



ja .

Voit yhdistää tämän toiminnon esim. hätänumeroon, vastaajaan tms.

Lyhytnumeron tallentaminen:

1. Etsi se numero, jonka haluat tallentaa lyhytnumeroksi.
2. Tallenna numero painamalla samanaikaisesti painikkeita  ja .
3. Lopeta ja palaa takaisin valmiustilaan painamalla .

Käännetty näyttö (LCD reverse)

Handsfree-laitteen näytön voi kääntää ylösalaisin sen mukaan, miten sitä käytät tai kuinka haluat sen asentaa.

- Valitse **LCD reverse** ja vahvista painamalla . Näyttö kääntyy ylösalaisin.

Mediasoitin (Media player)



Handsfree voi toistaa puhelimelle tallennettua musiikkia. Tämä edellyttää, että puhelin on A2DP-yhteensopiva ja tukee median virtausta Bluetoothilla.

Aloita toisto

1. Varmista, että matkapuhelin on yhteydessä handsfree-laitteeseen.
2. Aloita musiikin toisto matkapuhelimessa. Musiikki toistetaan handsfreessä ja näytöllä näkyy samalla kuulokesymboli.

Raidan vaihtaminen, toiston keskeyttäminen tai pysäyttäminen

Voi ohjata musiikin toistoa suoraan handsfree-laitteella.

1. Valitse **Media Player** ja vahvista painamalla .
2. Valitse haluamasi toiminto:
 - ▶ – Toisto
 - – Pysäytys
 - II – Tauko
 - ◀◀ – Edellinen raita
 - ▶▶ – Seuraava raita
3. Vahvista valintasi painamalla .

Huom. Voit ohjata toistoa myös tavalliseen tapaan matkapuhelimellasi.

Äänvoimakkuuden säätö

Säädä äänvoimakkuutta äänvoimakkuuspainikkeilla. Näytöllä näkyy asetettu äänvoimakkuus.



– Vähentää äänvoimakkuutta



– Lisää äänvoimakkuutta

Huom.!

- Jos äänvoimakkuus on liian korkea, se voi aiheuttaa kaikua puhelun aikana. Säädä äänvoimakkuus sopivalle tasolle.
- Älä paina äänvoimakkuuspainikkeita samanaikaisesti, koska silloin soitat lyhytnumeroon (hot key).

Huolto ja ylläpito

Pyyhi kevyesti kostutetulla liinalla. Älä käytä voimakkaita puhdistusaineita tai liuottimia.

Kierrätys

Kierrätä tuote asianmukaisesti, kun poistat sen käytöstä. Ota yhteys kuntasi jäteneuvontaan, mikäli olet epävarma.

Tekniset tiedot

Bluetooth-liitäntä	Versio 1.2 -yhteensopiva (luokka II). Adaptiivinen taajuushyppely (AFH). Pienempi häiriöriski. Data rate: 723 kbps. Radiohäiriöiden esto, esim. WLAN.
Profiili	A2DP/AV stereo.
Taajuus	2,45 GHz.
Kantama	noin 10 metriä (Luokka II).
Puhelinmuistio	Jopa 600 puhelinnumeroa.
Puhelintuki	Muistiin mahtuu 8 puhelinta.
Näyttö	Taustavalaistu numeronäyttö, jossa 4 riviä ja 18 merkkiä/rivi.
DSP	Full Duplex. Suhinan ja kaiun minimointi.
Puheaika	Jopa 8 tuntia.
Paristotyyppi	3 x HR03/AAA ladattavia akkuja (sisältyvät).
Ulkoinen käyttöjännite	12–24 V DC.
Kaiuttimen teho	2 W (maks.).
Ympäristön lämpötila	- 10 °C...40 °C.
Mitat (LxKxS)	120 x 23 x 93 mm.

Declaration of Conformity



Hereby, Clas Ohlson AB, declares that following product(s):

Hands free Car kit

Art. No: 36-3553, model: Alpha BSI012

is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Article 3.1a (Safety): EN 60950- 1

Article 3.1b (EMC): EN 301489-1, EN 301489-17

Article 3.2 (Radio): EN 300328

CE 0470

Insjön, Sweden, November 2008

A handwritten signature in black ink, appearing to read 'Klas Balkow', with a long horizontal flourish extending to the right.

Klas Balkow
President

Clas Ohlson, 793 85 Insjön, Sweden

This product's intended usage is within the countries of Sweden, Norway, Finland and United Kingdom

EXIBEL®

SVERIGE

KUNDTJÄNST

Tel: 0247/445 00, Fax: 0247/445 09

E-post: kundtjanst@clasohlson.se

www.clasohlson.se

INTERNET

NORGE

KUNDESENTER

Tlf: 23 21 40 00, Faks: 23 21 40 80

E-post: kundesenter@clasohlson.no

www.clasohlson.no

INTERNETT

SUOMI

ASIAKASPALVELU

Puh: 020 111 2222, Faksi: 020 111 2221

Sähköposti: info@clasohlson.fi

www.clasohlson.fi

Internet

GREAT BRITAIN

For consumer contact, please visit www.clasohlson.co.uk and click on customer service. Internet www.clasohlson.co.uk