


Please read the entire instruction manual before using the product and save it for future reference. We reserve the right for any errors in text or images and any necessary changes made to technical data. If you have any questions regarding technical problems please contact our Customer Services.

Safety

- This product must not be used by anyone (including children) suffering from physical or mental impairment. This product should not be used by anyone without sufficient experience or knowledge unless they have been instructed in its use by someone who will take full responsibility for their safety.
- Never let children play with the foot bath.
- Turn off and unplug the foot bath from the wall socket before cleaning it.
- Do not pull or carry the foot bath by the mains lead.
- Do not use the foot bath if it has a damaged mains lead or if it has been dropped or damaged in any way.
- Never use the foot bath for anything other than its intended use.
- The foot bath is only intended for indoor use
- Never dismantle the foot bath. The foot bath contains no replaceable parts.
- Always disconnect the mains lead after use.
- Never touch the foot bath if it has fallen into water. Immediately unplug it from the wall socket.
- Never use the foot bath when it is immersed in water.
- Never store the foot bath where it might fall into water or other liquid.
- Never unplug the foot bath from the mains when your feet are still in the water.
- Never use accessories that are not approved by the manufacturer or which do not accompany the foot bath.
- Never leave the foot bath unattended when it is on.
- Always check the temperature of the water before use to avoid scalding.
- Do not use the foot bath if it is leaking.
- Never stand up in the foot bath.
- Always unplug the foot bath from the mains before emptying, filling or moving it.
- The foot bath cannot heat up cold water.
- Make sure that your hands are dry when handling the foot bath and the plug.
- Keep the mains lead away from any heat sources.
- Never cover the foot bath.

- If you have a pacemaker, are pregnant or have diabetes, you should consult a doctor before using the foot bath.
- Never use the foot bath if you have open cuts or sores.
- Do not use bath oil, as it can affect the bubble effect.
- The mains lead must be changed if damaged. This is to prevent the risk of electric shock or fire and should only be carried out by the manufacturer, qualified service facility or qualified technician.
- This foot bath is designed exclusively for domestic use.

Product description



1. Selector switch with 4 settings: **Off – Vibration – Bubbles – Bubbles and vibration**
2. Splashguard
3. Basin
4. Massage accessories: Massage rollers or studded massage plate
5. Rubber feet
6. Pedicure tools: Pumice stone, brush and massage ball
7. Pedicure tool holder
8. Infrared lamp: Lights when the foot bath is in Bubbles or Bubbles and vibration setting.

Operating instructions

Make sure that the foot bath is unplugged whilst it is being filled.

1. Half-fill the basin with room-temperature water*.
2. Plug the mains lead into a wall socket.
3. Set the selector switch to the desired setting.
4. Sit on a chair, stool, sofa, etc and place your feet into the foot bath.
5. Switch the foot bath off before changing massage accessories or pedicure tools.

* The foot bath cannot heat up cold water, but it can keep the water warm in two of its settings: **Bubbles** and **Bubbles and vibration**. In the **keep-warm** settings, the water is slowly heated to a few degrees above its starting temperature.

Care and maintenance

- Pull out the plug and let the foot bath cool before cleaning.
- Clean the product using a soft, moist cloth. Use a mild detergent and never use solvents or strong, abrasive cleaning agents for cleaning as these can damage the product.
- The selector switch must not be splashed or exposed to water.
- The product must never be immersed in liquid.

Disposal

This product should be disposed of in accordance with local regulations. If you are unsure how to proceed, contact your local authority.

Specifications

Power supply 230 V AC, 50 Hz
Power 90 W